

OPERATION MANUAL

AC Servo Drive

FDA6000C Series

Ver 1.2 (Soft. Ver. 6.06 ~)

FDA6000C Series

Servo Drive User Manual

HIGEN

< CAUTION >

1. Check Motor ID certainly. (P1-01)
2. Check Drive Amp-Type certainly. (P1-10)

| Drive | 6001C | 6002C | 6004C | 6005C | 6010C | 6012C | 6015C | 6020C | 6030C | 6045C | 6075C | 6110C | 6150C |
|----------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| Amp Type | 0 | 1 | 2 | 5 | 6 | 7 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |

3. Check Encoder Pulse certainly. (P1-12)

Example) **FMALN09-AB00**

| Symbol | Pulse | Type |
|--------|-------|-------------------------|
| A | 2000 | Incremental 15 wires |
| B | 2500 | |
| C | 3000 | |
| D | 5000 | |
| E | 6000 | |
| F | 2048 | |
| G | 2048 | Absolute 11/13bit |

4. Operate servo system after autotuning is off. (P2-23)
5. Avoid impacting to the Motor in connecting. Especially, avoid impacting to the Encoder in connecting coupling to the Motor shaft or operating.
6. Recommended specifications in Encoder wiring.
Check Encoder Type and use authorized shield cable.

| Encoder Type | Reference Page |
|---------------------|----------------|
| Incremental Encoder | 3-16 |
| Absolute Encoder | 3-18 |

7. Treatment of the servo motor attached holding brake .
: The brake built in the servo motor is a normal closed type brake. Which is used only to hold and can not be used for braking. Use the holding brake only to hold a stopped servo motor.

Contents

1. Checking and Handling

| | | | |
|-----|----------------------|-------|-----|
| 1.1 | Handling | ----- | 1-1 |
| 1.2 | Caution during Use | ----- | 1-2 |
| 1.3 | Installation | ----- | 1-3 |
| 1.4 | Order Specifications | ----- | 1-7 |

2. Ratings and Specifications

| | | | |
|-----|---|-------|-----|
| 2.1 | Ratings and specifications for AC servo drive FDA6000C series | --- | 2-1 |
| 2.2 | AC Servo Motor Ratings and Specifications | ----- | 2-2 |

3. Wiring and Signals

| | | | |
|-----|--|-------|------|
| 3.1 | Power parts wiring | ----- | 3-2 |
| 3.2 | Connection and signal-form of input/output | ----- | 3-9 |
| 3.3 | CN1 Wiring and Signal | ----- | 3-12 |
| 3.4 | CN2 Wiring and Signal | ----- | 3-17 |

4. Digital Loader Operation

| | | | |
|-----|--------------------------|-------|-----|
| 4.1 | Handling and Menu system | ----- | 4-2 |
| 4.2 | Changing Parameters | ----- | 4-3 |

5. Parameter Setting

| | | | |
|------|---|-------|------|
| 5.1 | Parameter Summary | ----- | 5-1 |
| 5.2 | Motor and System Parameter (Motor Parameter: P1--) | ----- | 5-7 |
| 5.3 | Control Parameter (Control Mode: P2--) | ----- | 5-10 |
| 5.4 | Speed control parameter (Speed Mode : P3--) | ----- | 5-16 |
| 5.5 | Position control parameter (Position Mode: P4--) | ----- | 5-18 |
| 5.6 | Position Command Parameter(POS Command Mode : P5--) | ----- | 5-20 |
| 5.7 | Jog/Original Mode Parameter (Jog/Origin Mode : P6--) | ----- | 5-22 |
| 5.8 | Mechanical Parameter (Mechanical Mode : P7--) | ----- | 5-23 |
| 5.9 | Operational Mode Parameter (Operation Mode : P8--) | ----- | 5-25 |
| 5.10 | Description of servo status (Status Window: St--) | ----- | 5-31 |
| 5.11 | Alarm Status Display (Alarm Status : ALS--) | ----- | 5-33 |

Contents

6. Operation Mode and How to use

| | | |
|------------|---|-------------|
| 6.1 | An important point check and set items, when operation ----- | 6-1 |
| 6.2 | How to operate absolute position ----- | 6-3 |
| 6.3 | How to use relative position operation. ----- | 6-5 |
| 6.4 | How to use sequential operation. ----- | 6-6 |
| 6.5 | Setting of position, input and output ----- | 6-8 |
| 6.6 | Origin Operation ----- | 6-9 |
| 6.7 | How to JOG operation ----- | 6-11 |
| 6.8 | How to use Monitor ----- | 6-12 |

7. Maintenance and Inspection

| | | |
|------------|-------------------------------|------------|
| 7.1 | Caution ----- | 7-1 |
| 7.2 | Inspection Items ----- | 7-1 |
| 7.3 | Replacing Parts ----- | 7-2 |
| 7.4 | Maintenance ----- | 7-3 |

8. Troubleshooting

| | | |
|------------|--------------------------|------------|
| 8.1 | Servo Motor ----- | 8-1 |
| 8.2 | Servo drive ----- | 8-2 |

9. External View

| | | |
|------------|--|------------|
| 9.1 | External Dimensions of AC Servo Drive ----- | 9-1 |
| 9.2 | External Dimensions of AC Servo Motor ----- | 9-2 |

10. Specifications of options


| | | |
|-------------|--|-------------|
| 10.1 | AC servo motor cable specifications ----- | 10-1 |
| 10.2 | AC servo drive ----- | 10-3 |

[Appendix] Revision History

1. Checking and Handling

1.1 Handling (Connection of main circuit and motor)

Thank you for purchasing HIGEN AC Servo Drive. Incorrect handling of the drive may lead to unsatisfactory operation or, in some cases, to the rapid reduction of its life, or damage to the servo system. Handle and operate the drive according to the instructions given in this manual.




1.2 Caution during Use


Improper handling of the drive may lead to unexpected accident or damage. The following are important points in drive operation.

1.2.1 Handling

- Avoid impact to the encoder, the motor detector.
Striking the shaft with a hammer or dropping the motor may cause unexpected damage.



- Do not connect commercial power supply (AC 220V) directly to the motor.
Direct connection induces flow of over current leading to demagnetize the magnet in motor.
Always use motor with specified servo drive.



1.2.2 Wiring

- Connect the drive and the motor earth terminals in the direction of the drive, and ground the terminals at the shortest distance at a time. To prevent both electric shock and improper operation, use class-3 earth (Less than 100 Ω).
- Always match the U, V, W and FG terminals of the motor with those of the drive. You cannot change the direction of rotation by changing 2 wires the same as in the case of widely used general motors.
- Connecting commercial power supply to the U, V, W and FG terminals of the drive may cause damage.
(Apply 200V power supply to R, S and T terminals)
Use a transformer in case power supply is other than 200V.
- Connect standard regenerative resistor to the P and B terminals of the drive.

1.2.3 Operation

- Use the magnetic brake of the motor only for emergency and maintenance (preservation).
The brake is designed for maintenance (preservation) during power outage. If used to reduce the speed, the brake wears out quickly.
- Install brakes and magnetic contactors on power supply terminals R, S and T.
In case an error occurs or abnormal current flows, shut off the circuit to prevent secondary fire.

1.2.4 Maintenance and inspection

- "High voltage" still remains inside the drive for a while even after power supply is shut off.
(Danger!)
To prevent electric-shock, carry out wiring work or inspection at least 10 minutes after the power is cut off and the charge lamp is turned off.
- The regenerative resistor and the servo motor remain hot for a while after power is turned off.
Touching them may cause burns.
- Megger test on the drive may cause damage to the drive. Do not perform megger test.
- Do not disassemble the motor detector. never remove the cover.

1.3 Installation

1.3.1 Installation of servo drive

- Operating environment

| | |
|---------------------|--|
| Ambient temperature | 0-50 (There should be no freezing) ^{Note} |
| Ambient humidity | 90% RH or lower (There should be no vapor) |

Note) Inside panel temperature specifications: To ensure maximum operating life and reliability of the drive, maintain the average panel temperature at 40 or lower.

Chapter 1. Checking and Handling

- Installation direction and intervals
 - Install FDA6000C can be seen from the front.
 - If the drives are installed in a closed panel, maintain an interval of more than 10 mm between drives and more than 40 mm between top and bottom. If multiple number of panels are installed in parallel, about 100 mm space is required on the upper side.
In case of installing fans, avoid heat.
 - Regenerative resistor, heating source, away from the drive.
- Prevention of infiltration of outside materials
 - Exercise caution when drilling control panels to prevent chips produced by drilling from getting into the drive.
 - Take appropriate measures to prevent oils, water and metal powder from getting into the drive from openings in the control panels and the fan installed on the ceiling.
 - If the drive is used in a place with large amount of toxic gases and dust, protect the drive with an air purge.

1.3.2 Servo motor installation


- Operating environment

| | |
|---------------------|--|
| Ambient temperature | 0-40 (There should be no freezing) |
| Ambient humidity | 80% RH or lower (There should be no vapor) |
| External vibration | X, Y = 19.6 m/s ² (2G) |

- Caution when assembling load system (Prevent impact on shaft)

It is important to accurately match the motor shaft with the shaft center of the connecting machine. Mismatched shaft center causes vibration, and may cause damage to the bearing. Use a rubber hammer to install couplings to prevent excessive force from being applied to the shaft and bearing.

Check 4 places in turn. The difference between maximum and minimum should be 0.03 or lower.



- Load tolerance on shaft
 - Use flexible couplings, and maintain the shaft center deviations within the specified tolerance.
 - Use pulleys and sprockets with the allowable load.

| MOTOR MODEL | | RADIAL LOAD | | AXIAL LOAD | | REFERENCE DIAGRAM |
|-------------|-------------|-------------|-----|------------|-----|-------------------|
| Series | Type | N | Kgf | N | kgf | |
| CN | CN01~CN05 | 196 | 20 | 68 | 7 | |
| | CN04A~CN10 | 245 | 25 | 98 | 10 | |
| | CN09~CN30 | 686 | 70 | 343 | 35 | |
| | CN30A~CN50A | 1470 | 150 | 490 | 50 | |
| KN | KN03~KN07 | 245 | 25 | 98 | 10 | |
| | KF06A~KN22 | 686 | 70 | 343 | 35 | |
| | KN22A~KN70 | 1470 | 150 | 490 | 50 | |
| TN | TN05~TN17 | 686 | 70 | 343 | 35 | |
| | TN20~TN75 | 1470 | 150 | 490 | 50 | |
| | TN110~TN150 | 1764 | 180 | 588 | 60 | |
| LN | LN03~LN12 | 686 | 70 | 343 | 35 | |
| | LN12A~LN55 | 1470 | 150 | 490 | 50 | |
| KF | KF08~KF15 | 686 | 70 | 343 | 35 | |
| | KF22~KF50 | 1470 | 150 | 490 | 50 | |
| TF | TF05~TF13 | 686 | 70 | 343 | 35 | |
| | TF20~TF44 | 1470 | 150 | 490 | 50 | |
| LF | LF03~LF09 | 686 | 70 | 343 | 35 | |
| | LF12~LF30 | 1470 | 150 | 490 | 50 | |

- Accuracy of attachments

The accuracies of the shaft and attachments of the AC servo motor are shown on the following table.



| Item | Accuracy (T.I.R.) | Reference Diagram |
|--|----------------------|-------------------|
| Perpendicularity of flange attachment plane and output shaft (A) | 0.04mm | |
| Eccentricity of flange fitting outer diameter (B) | 0.04mm | |
| Vibration of shaft end (C) | 0.02mm | |

(Note) T.I.R : Total Indicator Reading

- **Impact resistance**

The drive withstands two times of impacts with an acceleration of 10G when up-and-down impacts are applied after setting the motor shaft horizontally.

However, a precision detector is attached to the end of the shaft on the opposite side of the load, take caution not to apply impact directly to this end.



- **Vibration resistance**

The drive withstands a vibration acceleration of 2.0G when vibration is applied in up and down, left and right, and front and back directions after setting the motor shaft horizontally.

- **Vibration grade**

The vibration grade of the AC servo motor is V15 at the rated rpm.

- **Direction of installation**

- Motor can be installed horizontally or at the top or bottom of the shaft.
- Keep the motor cable downward.
- If the motor is installed vertically, install a cable trap so that oils or water do not flow into the motor.


- **Cable disconnection**

- Take caution not to cause stress or damage to the cables.
- If the motor is used as a mobile motor, use flexible cables.


1.4 Order Specifications

Prior to installing the product, check the ratings plate to see if the related specifications match with those of the order.

1.4.1 Servo motor model marking



1.4.2 Servo drive model marking



1.4.3 AC Servo application table

| Motor | Drive | | 6001 C | 6002 C | 6004 C | 6005 C | 6010 C | 6012 C | 6015 C | 6020 C | 6030 C | 6045 C | 6075 CN | 6110 CN | 6150 CN |
|--|--|-------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|------------|------------|------------|
| | Flange | Model | | | | | | | | | | | | | |
| CK Series 3000 /5000 (r/min) | 40 | CKZ5 | | | | | | | | | | | | | |
| | | CK01 | | | | | | | | | | | | | |
| | 60 | CK02 | | | | | | | | | | | | | |
| | | CK04 | | | | | | | | | | | | | |
| | CN Series 3000 /5000 (r/min) | CN01 | | | | | | | | | | | | | |
| | | CN02 | | | | | | | | | | | | | |
| | | CN03 | | | | | | | | | | | | | |
| | | CN04 | | | | | | | | | | | | | |
| | | CN05 | | | | | | | | | | | | | |
| KN Series 2000 /3000 (r/min) | 80 | CN04A | | | | | | | | | | | | | |
| | | CN06 | | | | | | | | | | | | | |
| | | CN08 | | | | | | | | | | | | | |
| | | CN10 | | | | | | | | | | | | | |
| | 130 | CN09 | | | | | | | | | | | | | |
| | | CN15 | | | | | | | | | | | | | |
| | | CN22 | | | | | | | | | | | | | |
| | | CN30 | | | | | | | | | | | | | |
| TN Series 1500 /3000 (r/min) | 180 | CN30A | | | | | | | | | | | | | |
| | | CN50A | | | | | | | | | | | | | |
| | | CN70 | | | | | | | | | | | | | |
| | | KN03 | | | | | | | | | | | | | |
| | 80 | KN05 | | | | | | | | | | | | | |
| | | KN06 | | | | | | | | | | | | | |
| | | KN07 | | | | | | | | | | | | | |
| | | KN06A | | | | | | | | | | | | | |
| 1500/2000 (r/min) | 130 | KN11 | | | | | | | | | | | | | |
| | | KN16 | | | | | | | | | | | | | |
| | | KN22 | | | | | | | | | | | | | |
| | | KN22A | | | | | | | | | | | | | |
| | 180 | KN35 | | | | | | | | | | | | | |
| | | KN55 | | | | | | | | | | | | | |
| | | KN70 | | | | | | | | | | | | | |
| | | TN05 | | | | | | | | | | | | | |
| 1500/2000 (r/min) | 130 | TN09 | | | | | | | | | | | | | |
| | | TN13 | | | | | | | | | | | | | |
| | | TN17 | | | | | | | | | | | | | |
| | | TN20 | | | | | | | | | | | | | |
| | 180 | TN30 | | | | | | | | | | | | | |
| | | TN44 | | | | | | | | | | | | | |
| | | TN55 | | | | | | | | | | | | | |
| | | TN75 | | | | | | | | | | | | | |
| 220 | TN110 | | | | | | | | | | | | | | |
| | TN150 | | | | | | | | | | | | | | |

| Motor | Drive | | 6001 C | 6002 C | 6004 C | 6005 C | 6010 C | 6012 C | 6015 C | 6020 C | 6030 C | 6045 C | 6075 CN | 6110 CN | 6150 CN |
|---|--------|-------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|------------|------------|------------|
| | Flange | Model | | | | | | | | | | | | | |
| LN Series <i>1000 /2000 (r/min)</i> | 130 | LN03 | | | | | | | | | | | | | |
| | | LN06 | | | | | | | | | | | | | |
| | | LN09 | | | | | | | | | | | | | |
| | | LN12 | | | | | | | | | | | | | |
| | 180 | LN12A | | | | | | | | | | | | | |
| | | LN20 | | | | | | | | | | | | | |
| | | LN30 | | | | | | | | | | | | | |
| | | LN40 | | | | | | | | | | | | | |
| | | LN55 | | | | | | | | | | | | | |
| KF Series <i>2000 /3000 (r/min)</i> | 130 | KF08 | | | | | | | | | | | | | |
| | | KF10 | | | | | | | | | | | | | |
| | | KF15 | | | | | | | | | | | | | |
| | 180 | KF22 | | | | | | | | | | | | | |
| | | KF35 | | | | | | | | | | | | | |
| | | KF50 | | | | | | | | | | | | | |
| TF Series <i>1500 /3000 (r/min)</i> | 130 | TF05 | | | | | | | | | | | | | |
| | | TF09 | | | | | | | | | | | | | |
| | | TF13 | | | | | | | | | | | | | |
| | 180 | TF20 | | | | | | | | | | | | | |
| | | TF30 | | | | | | | | | | | | | |
| | | TF44 | | | | | | | | | | | | | |
| LF Series <i>1000 /2000 (r/min)</i> | 130 | LF03 | | | | | | | | | | | | | |
| | | LF06 | | | | | | | | | | | | | |
| | | LF09 | | | | | | | | | | | | | |
| | 180 | LF12 | | | | | | | | | | | | | |
| | | LF20 | | | | | | | | | | | | | |
| | | LF30 | | | | | | | | | | | | | |

Chapter 2. Ratings and Specifications

2. Ratings and Specifications

2.1 Ratings and specifications for AC servo drive FDA6000C series

| Model [FDA-] | | 6001 C | 6002 C | 6004 C | 6005 C | 6010 C | 6012 C | 6015 C | 6020 C | 6030 C | 6045 C | 6075 CN | 6110 CN | 6150 CN | | | | | | | | | | | | |
|---------------------------------|-------------------------------|---|---|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|------------|------------|------------|--|--|--|--|--|--|--|--|--|--|--|--|
| Input power supply | Power supply voltage *(note1) | 3 phase AC200~230V +10/-15%, 50/60Hz | | | | | | | | | | | | | | | | | | | | | | | | |
| Applicable motor | Power capacity [kVA] | 0.5 | 0.8 | 1.3 | 1.5 | 2.1 | 2.5 | 3.1 | 4.1 | 6.0 | 8.0 | 12.0 | 17.6 | 24 | | | | | | | | | | | | |
| Applicable motor | Voltage type | 3 phase sine wave drive AC servo motor | | | | | | | | | | | | | | | | | | | | | | | | |
| | Continuous output current [A] | 1.25 | 2.1 | 3.2 | 4.2 | 6.9 | 9.8 | 11 | 16 | 21 | 32 | 49.6 | 54.5 | 73.7 | | | | | | | | | | | | |
| | Maximum output current [A] | 3.8 | 6.3 | 9.6 | 12.6 | 19.2 | 29 | 33 | 48 | 63 | 96 | 119 | 131 | 192.5 | | | | | | | | | | | | |
| Detector | Detector model | Standard : Incremental 2000 [p/rev] 15-wire type Option : Absolute 2048 [p/rev] 11/13bit | | | | | | | | | | | | | | | | | | | | | | | | |
| | Output signal type | Differential Line Driver output | | | | | | | | | | | | | | | | | | | | | | | | |
| | Detector accuracy | 1000 ~ 10000 [p/rev] (Not to exceed 400 [kp/sec]) | | | | | | | | | | | | | | | | | | | | | | | | |
| | Detector power supply | Not to exceed DC 5[V], 0.3 [A] | | | | | | | | | | | | | | | | | | | | | | | | |
| Drive system | | 3-phase voltage type PWM drive (IPM used) | | | | | | | | | | | | | | | | | | | | | | | | |
| Run Mode Specification | Absolute Mode | Position setting | Absolute position data(32 points) setting | | | | | | | | | | | | | | | | | | | | | | | |
| | | Command input | Select absolute position data(32 points) by input contact | | | | | | | | | | | | | | | | | | | | | | | |
| | | System | Absolute position command method, short distance discrimination function | | | | | | | | | | | | | | | | | | | | | | | |
| | Relative Mode | Position setting | Relative position data(32 points) setting | | | | | | | | | | | | | | | | | | | | | | | |
| | | Command input | Select relative position data(32 points) by input contact | | | | | | | | | | | | | | | | | | | | | | | |
| | Sequence Mode | System | Relative position command method | | | | | | | | | | | | | | | | | | | | | | | |
| | | Position setting | Position data 4 points setting | | | | | | | | | | | | | | | | | | | | | | | |
| Position control specifications | MPG | System | Sequence loop operation, select Step/Auto operation | | | | | | | | | | | | | | | | | | | | | | | |
| | | Input frequency | 500[kpps] | | | | | | | | | | | | | | | | | | | | | | | |
| | | Pulse Logic | Direction + pulse, forward run pulse + reverse run pulse 2-phase pulse (A phase + B phase) | | | | | | | | | | | | | | | | | | | | | | | |
| | Jog operation | Input Type | Open collector, line driver system | | | | | | | | | | | | | | | | | | | | | | | |
| | | Origin Rule | Be selected by parameter | | | | | | | | | | | | | | | | | | | | | | | |
| | | Speed override function | Be set by parameter | | | | | | | | | | | | | | | | | | | | | | | |
| | | Speed accel/decel time | Able to set 4 patterns(8 positions/ 1 pattern) | | | | | | | | | | | | | | | | | | | | | | | |
| Built-in functions | Protective functions | Overcurrent, regenerative overvoltage, overload, motor miswiring, drive overheat, encoder error, voltage shortage, overspeed and excessive error. | | | | | | | | | | | | | | | | | | | | | | | | |
| | Regenerative resistor | Standard separately attached type | | | | | | | | | | | | | | | | | | | | | | | | |
| | Monitor output | Speed, torque and position (-4 ~ +4 [V]) | | | | | | | | | | | | | | | | | | | | | | | | |
| | Dynamic brake | built in | | | | | | | | | | | | | | | | | | | | | | | | |
| | Additional function | Testing function (jog operation), alarm history, forward and backward run, encoder signal frequency division output | | | | | | | | | | | | | | | | | | | | | | | | |
| Option | | Digital Loader , Power cable, encoder cable, CN1 connector, CN2 connector | | | | | | | | | | | | | | | | | | | | | | | | |
| Environmental specifications | Operating ambient temperature | 0-50 [°C] | | | | | | | | | | | | | | | | | | | | | | | | |
| | Ambient humidity | Not to exceed 90 [%] (Should be free of dewing) | | | | | | | | | | | | | | | | | | | | | | | | |
| | Storage temperature | -20 ~ +80 [°C] | | | | | | | | | | | | | | | | | | | | | | | | |
| | Insulating resistance | To be greater than DC 500 [V] 10 [MΩ] | | | | | | | | | | | | | | | | | | | | | | | | |
| Structure | | Book Type | | | | | | | | | | | | | | | | | | | | | | | | |

(Note 1) The model name of the servo drive, which uses absolute encoder, is FDA6000CA.


(Note 2) Single-phase AC 220V can also be used. However, as output may become lower than the rated value, raise the servo drive capacity by 1 step if possible.

2.2 AC Servo Motor Ratings and Specifications

| Model Spec. | Motor | CKZ5 | CK01 | CK02 | CK04 |
|--|-------------------|-----------------------------|-------|-------|-------|
| | Drive | 6001C | 6001C | 6002C | 6004C |
| Flange size (□) | 40 | | | 60 | |
| Rated output (W) | 50 | 100 | 200 | 400 | |
| Rated torque | (N·m) | 0.16 | 0.32 | 0.64 | 1.27 |
| | (kgf·cm) | 1.62 | 3.25 | 6.5 | 13.0 |
| Maximum instantaneous torque | (N·m) | 0.48 | 0.95 | 1.92 | 3.81 |
| | (kgf·cm) | 4.87 | 9.74 | 1.95 | 39.0 |
| Rated rpm (r/min) | 3000 | | | | |
| Maximum rpm (r/min) | 5000 | | | | |
| Rotor inertia (= $GD^2/4$) ($\text{kg}\cdot\text{m}^2 \times 10^{-4}$) | 0.049 | 0.081 | 0.246 | 0.440 | |
| Allowable load inertia Ratio(Versus rotor) | 15 times or below | | | | |
| Rated power rate (kW/s) | 5.3 | 12.8 | 16.5 | 36.8 | |
| Detector type | Standard | Incremental 2000 | | | |
| | Option | Absolute 11/13bit 2048P/rev | | | |
| Weight (kg) | 0.42 | 0.55 | 1.0 | 1.73 | |

Speed and Torque Characteristics

A : Continuous duty zone & B : Intermittent duty zone




Chapter 2. Ratings and Specifications

| Model Spec. | Motor | CN01 | CN02 | CN03 | CN04 | CN05 | CN04A | CN06 | CN08 | CN10 |
|--|--|-----------------------------|-------|-------|-------|-------|------------------------|------|-------|-------|
| | Drive | 6001C | 6002C | | 6004C | | | | 6005C | 6010C |
| Flange size (□) | | 60 | | | | | | | | 80 |
| Rated output (W) | | 100 | 200 | 300 | 400 | 500 | 400 | 600 | 800 | 1000 |
| Rated torque | (N·m) | 0.32 | 0.64 | 0.96 | 1.27 | 1.59 | 1.27 | 1.91 | 2.54 | 3.18 |
| | (kgf·cm) | 3.25 | 6.5 | 9.75 | 13.0 | 16.2 | 13.0 | 19.5 | 26.0 | 32.5 |
| Maximum instantaneous torque | (N·m) | 0.96 | 1.92 | 2.88 | 3.81 | 4.77 | 3.81 | 5.3 | 6.85 | 9.53 |
| | (kgf·cm) | 9.75 | 19.5 | 29.3 | 39.0 | 48.7 | 39.0 | 54.5 | 70.2 | 97.5 |
| Rated rpm (r/min) | | 3000 | | | | | | | | |
| Maximum rpm (r/min) | | 5000 | | | | | | | | |
| Rotor inertia (= $GD^2/4$) | (gf·cm·s ²) | 0.061 | 0.095 | 0.126 | 0.160 | 0.204 | 1.1 | 1.5 | 1.77 | 2.11 |
| | (kg·m ² × 10 ⁻⁴) | 0.06 | 0.093 | 0.129 | 0.163 | 0.208 | 1.08 | 1.47 | 1.74 | 2.07 |
| Allowable load inertia Ratio(Versus rotor) | | Not exceeding 30 times | | | | | Not exceeding 20 times | | | |
| Rated power rate (kW/s) | | 17.0 | 43.6 | 73.9 | 103.5 | 126.1 | 15.0 | 24.8 | 37.4 | 49.0 |
| Detector type | Standard | Incremental 2000 | | | | | | | | |
| | Option | Absolute 11/13bit 2048P/rev | | | | | | | | |
| Weight (kg) | | 0.85 | 1.14 | 1.43 | 1.73 | 2.03 | 2.1 | 2.55 | 3.1 | 3.7 |

Speed and Torque Characteristics


A : Continuous duty zone & B : Intermittent duty zone



| Model Spec. | Motor | CN09 | CN15 | CN22 | CN30 | CN30A | CN50A |
|---|-----------------------------|------------------|-------|-------|-------|-------|-------|
| Drive | 6010C | 6015C | 6020C | 6030C | 6030C | 6045C | |
| Flange size (□) | 130 | | | | | 180 | |
| Rated output (W) | 900 | 1500 | 2200 | 3000 | 3000 | 5000 | |
| Rated torque (N · m) | 2.86 | 4.77 | 7.0 | 9.54 | 9.54 | 15.9 | |
| (kgf · cm) | 29.2 | 48.7 | 71.4 | 97.4 | 97.4 | 162.3 | |
| Maximum instantaneous torque (N · m) | 8.6 | 14.3 | 21 | 28.6 | 23.9 | 39.8 | |
| (kgf · cm) | 87.6 | 146 | 214 | 292 | 243.5 | 405.8 | |
| Rated rpm (r/min) | 3000 | | | | | | |
| Maximum rpm (r/min) | 5000 | | | | 4500 | | |
| Rotor inertia (= $GD^2/4$) (kg · m ² × 10 ⁻⁴) | 4.12 | 7.63 | 11.12 | 14.63 | 26.1 | 43.8 | |
| Allowable load inertia Ratio(Versus rotor) | Not exceeding 10 times | | | | | | |
| Rated power rate (kW/s) | 20.4 | 30.6 | 45.1 | 63.9 | 35.7 | 58.9 | |
| Detector type | Standard | Incremental 2000 | | | | | |
| Option | Absolute 11/13bit 2048P/rev | | | | | | |
| Weight (kg) | 5.5 | 7.0 | 8.5 | 10.0 | 12.9 | 18.2 | |

Speed and Torque Characteristics

A : Continuous duty zone & B : Intermittent duty zone




Chapter 2. Ratings and Specifications

| Model Spec. | Motor | KN03 | KN05 | KN06 | KN07 |
|--|--|-----------------------------|-------|-------|-------|
| | Drive | 6004C | 6004C | 6005C | 6010C |
| Flange size (□) | 80 | | | | |
| Rated output (W) | | 300 | 450 | 550 | 650 |
| Rated torque | (N · m) | 1.43 | 2.15 | 2.57 | 3.04 |
| | (kgf · cm) | 14.6 | 21.9 | 26.2 | 31 |
| Maximum instantaneous torque | (N · m) | 4.29 | 6.45 | 7.42 | 9.12 |
| | (kgf · cm) | 43.8 | 65.7 | 72.7 | 93 |
| Rated rpm (r/min) | 2000 | | | | |
| Maximum rpm (r/min) | 3000 | | | | |
| Rotor inertia (= $GD^2/4$) | (gf · cm · s ²) | 1.1 | 1.5 | 1.77 | 2.11 |
| | (kg · m ² × 10 ⁻⁴) | 1.08 | 1.47 | 1.74 | 2.07 |
| Allowable load inertia Ratio(Versus rotor) | Not exceeding 20 times | | | | |
| Rated power rate (kW/s) | 18.9 | 31.3 | 38.0 | 44.6 | |
| Detector type | Standard | Incremental 2000 | | | |
| | Option | Absolute 11/13bit 2048P/rev | | | |
| Weight (kg) | 2.1 | 2.55 | 3.1 | 3.7 | |

Speed and Torque Characteristics


A : Continuous duty zone & B : Intermittent duty zone



| Model Spec. | Motor | KN06A | KN11 | KN16 | KN22 | KN22A | KN35 | KN55 |
|--|--|-----------------------------|-------|-------|-------|-------|-------|-------|
| Drive | 6005C | 6010C | 6015C | 6020C | 6020C | 6030C | 6045C | |
| Flange size (□) | 130 | | | | | | 180 | |
| Rated output (W) | 600 | 1100 | 1600 | 2200 | 2200 | 3500 | 5500 | |
| Rated torque | (N·m) | 2.86 | 5.25 | 7.64 | 10.5 | 10.49 | 16.67 | 26.18 |
| | (kgf·cm) | 29.2 | 53.6 | 77.9 | 107 | 107 | 170 | 267 |
| Maximum instantaneous torque | (N·m) | 8.6 | 14.2 | 22.5 | 31.5 | 31.5 | 50.1 | 65.4 |
| | (kgf·cm) | 87.6 | 145 | 230 | 321 | 321 | 510 | 667.5 |
| Rated rpm (r/min) | 2000 | | | | | | | |
| Maximum rpm (r/min) | 3000 | | | | | | | |
| Rotor inertia (= $GD^2/4$) | (gf·cm·s ²) | 4.12 | 7.63 | 11.12 | 14.63 | 26.1 | 43.8 | 67.8 |
| | (kg·m ² × 10 ⁻⁴) | 4.04 | 7.48 | 10.9 | 14.34 | 25.6 | 42.9 | 66.4 |
| Allowable load inertia Ratio(Versus rotor) | Not exceeding 10 times | | | | | | | |
| Rated power rate (kW/s) | 20.4 | 30.6 | 53.5 | 76.7 | 43.0 | 64.7 | 103.0 | |
| Detector type | Standard | Incremental 2000 | | | | | | |
| | Option | Absolute 11/13bit 2048P/rev | | | | | | |
| Weight (kg) | 5.5 | 7.0 | 8.5 | 10.0 | 12.9 | 18.2 | 26.8 | |

Speed and Torque Characteristics

A : Continuous duty zone & B : Intermittent duty zone




Chapter 2. Ratings and Specifications

| Model Spec. | Motor | TN05 | TN09 | TN13 | TN17 | TN20 | TN30 | TN44 | TN75 | TN110 | TN150 |
|--|--|-----------------------------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|------------|------------|
| | Drive | 6005 C | 6010 C | 6015 C | 6020 C | 6020 C | 6030 C | 6045 C | 6075 C | 6110 CN | 6150 CN |
| Flange size (□) | | 130 | | | | | | 180 | | | 220 |
| Rated output (W) | | 450 | 850 | 1300 | 1700 | 1800 | 2900 | 4400 | 7500 | 11000 | 15000 |
| Rated torque | (N·m) | 2.87 | 5.41 | 8.27 | 10.8 | 11.5 | 18.6 | 27.9 | 47.7 | 70 | 95.4 |
| | (kgf·cm) | 29.3 | 55.2 | 84.4 | 110 | 117 | 190 | 285 | 486.9 | 714 | 97.4 |
| Maximum instantaneous torque | (N·m) | 8.61 | 14.2 | 22.5 | 29.4 | 34.5 | 46.6 | 69.9 | 119.3 | 175 | 229 |
| | (kgf·cm) | 89.5 | 145 | 230 | 300 | 351 | 475 | 712.5 | 1217 | 1785 | 2434 |
| Rated rpm (r/min) | | 1500 | | | | | | | | | |
| Maximum rpm (r/min) | | 3000 | | | | | | | | 2000 | |
| Rotor inertia (= $GD^2/4$) | (gf·cm·s ²) | 4.12 | 7.63 | 11.12 | 14.63 | 26.1 | 43.8 | 67.8 | 126.4 | 211 | 308 |
| | (kg·m ² × 10 ⁻⁴) | 4.04 | 7.48 | 10.9 | 14.34 | 25.1 | 42.9 | 66.4 | 123.9 | 207 | 302 |
| Allowable load inertia Ratio(Versus rotor) | | Not exceeding 10 times | | | | | | | | | |
| Rated power rate (kW/s) | | 20.5 | 39.1 | 62.8 | 81.1 | 51.5 | 80.8 | 117.4 | 183.8 | 236 | 301 |
| Detector type | Standard | Incremental 2000 | | | | | | | | | |
| | Option | Absolute 11/13bit 2048P/rev | | | | | | | | | |
| Weight (kg) | | 5.5 | 7.0 | 8.5 | 10.0 | 12.9 | 18.2 | 26.8 | 45.7 | 59 | 84 |

Speed and Torque Characteristics


A : Continuous duty zone & B : Intermittent duty zone



| Model Spec. | Motor | LN03 | LN06 | LN09 | LN12 | LN12A | LN20 | LN30 | LN40 |
|--|--|-----------------------------|-------|-------|-------|-------|-------|-------|--------|
| | Drive | 6004C | 6005C | 6010C | 6012C | 6012C | 6020C | 6030C | 6045C |
| Flange size (□) | | 130 | | | | | | 180 | |
| Rated output (W) | | 300 | 600 | 900 | 1200 | 1200 | 2000 | 3000 | 4000 |
| Rated torque | (N·m) | 2.86 | 5.72 | 8.6 | 11.5 | 11.5 | 19.1 | 28.6 | 38.2 |
| | (kgf·cm) | 29.2 | 58.4 | 87.7 | 117 | 116.9 | 194.8 | 292.2 | 389.6 |
| Maximum instantaneous torque | (N·m) | 8.6 | 14.3 | 22.1 | 34.4 | 28.7 | 57.3 | 71.6 | 114.6 |
| | (kgf·cm) | 87.6 | 146 | 226 | 351 | 292.3 | 584.4 | 730.5 | 1168.8 |
| Rated rpm (r/min) | | 1000 | | | | | | | |
| Maximum rpm (r/min) | | 2000 | | | | | | | |
| Rotor inertia (= $GD^2/4$) | (gf·cm·s ²) | 4.12 | 7.63 | 11.12 | 14.63 | 26.1 | 43.8 | 67.8 | 100.1 |
| | (kg·m ² × 10 ⁻⁴) | 4.04 | 7.48 | 10.9 | 14.34 | 25.6 | 42.9 | 66.4 | 98.1 |
| Allowable load inertia Ratio(Versus rotor) | | Not exceeding 10 times | | | | | | | |
| Rated power rate (kW/s) | | 20.5 | 43.3 | 68.2 | 91.7 | 51.4 | 84.9 | 123.4 | 148.6 |
| Detector type | Standard | Incremental 2000 | | | | | | | |
| | Option | Absolute 11/13bit 2048P/rev | | | | | | | |
| Weight (kg) | | 5.5 | 7.0 | 8.5 | 10.0 | 12.9 | 18.2 | 26.8 | 36.1 |

Speed and Torque Characteristics

A : Continuous duty zone & B : Intermittent duty zone




Chapter 2. Ratings and Specifications

| Model Spec. | Motor | KF08 | KF10 | KF15 | KF22 | KF35 | KF50 |
|--|--|-----------------------------|-------|-------|-------|-------|-------|
| | Drive | 6010C | | 6015C | 6020C | 6030C | 6045C |
| Flange size (□) | | 130 | | | 180 | | |
| Rated output (W) | | 750 | 1000 | 1500 | 2200 | 3500 | 5000 |
| Rated torque | (N·m) | 3.58 | 4.77 | 7.16 | 10.5 | 16.7 | 23.9 |
| | (kgf·cm) | 36.53 | 48.7 | 73.1 | 107 | 170 | 244 |
| Maximum instantaneous torque | (N·m) | 10.74 | 14.31 | 21.56 | 31.4 | 50.0 | 71.7 |
| | (kgf·cm) | 109.5 | 146.0 | 220.0 | 321 | 510 | 732 |
| Rated rpm (r/min) | | 2000 | | | 3000 | | |
| Maximum rpm (r/min) | | 2000 | | | 3000 | | |
| Rotor inertia (= $GD^2/4$) | (gf·cm·s ²) | 10.5 | 15.5 | 25.3 | 65.3 | 100.5 | 159.1 |
| | (kg·m ² × 10 ⁻⁴) | 10.3 | 15.2 | 24.8 | 64.0 | 98.5 | 156 |
| Allowable load inertia Ratio(Versus rotor) | | Not exceeding 10 times | | | | | |
| Rated power rate (kW/s) | | 12.3 | 15.0 | 20.7 | 17.2 | 28.2 | 36.4 |
| Detector type | Standard | Incremental 2000 | | | | | |
| | Option | Absolute 11/13bit 2048P/rev | | | | | |
| Weight (kg) | | 8.2 | 11.6 | 15.8 | 17.2 | 27.4 | 38.3 |


Speed and Torque Characteristics

A : Continuous duty zone & B : Intermittent duty zone


KF08




KF10




KF15




KF22



KF35




KF50



| Model Spec. | Motor | TF05 | TF09 | TF13 | TF20 | TF30 | TF44 | |
|--|--|-----------------------------|-------|-------|-------|-------|-------|--|
| Drive | 6005C | 6010C | 6015C | 6020C | 6030C | 6045C | | |
| Flange size (□) | 130 | | | | 180 | | | |
| Rated output (W) | 450 | 850 | 1300 | 1800 | 2900 | 4400 | | |
| Rated torque | (N·m) | 2.87 | 5.41 | 8.27 | 11.5 | 18.6 | 27.9 | |
| | (kgf·cm) | 29 | 55 | 85 | 117 | 190 | 285 | |
| Maximum instantaneous torque | (N·m) | 8.61 | 14.7 | 24.5 | 34.4 | 55.9 | 77.5 | |
| | (kgf·cm) | 89.5 | 150 | 250 | 351 | 570 | 790 | |
| Rated rpm (r/min) | 1500 | | | | | | | |
| Maximum rpm (r/min) | 3000 | | | | | | | |
| Rotor inertia (= $GD^2/4$) | (gf·cm·s ²) | 10.5 | 15.5 | 25.3 | 65.3 | 100.5 | 159.1 | |
| | (kg·m ² × 10 ⁻⁴) | 10.3 | 15.2 | 24.8 | 64.0 | 98.5 | 156 | |
| Allowable load inertia Ratio(Versus rotor) | Not exceeding 10 times | | | | | | | |
| Rated power rate (kW/s) | 7.85 | 19.1 | 28.0 | 20.5 | 35.2 | 50.0 | | |
| Detector type | Standard | Incremental 2000 | | | | | | |
| | Option | Absolute 11/13bit 2048P/rev | | | | | | |
| Weight (kg) | 8.2 | 11.6 | 15.8 | 17.2 | 27.4 | 38.3 | | |

Speed and Torque Characteristics

A : Continuous duty zone & B : Intermittent duty zone




Chapter 2. Ratings and Specifications


| Model Spec. | Motor | LF03 | LF06 | LF09 | LF12 | LF20 | LF30 |
|--|--|-----------------------------|-------|-------|-------|-------|-------|
| | Drive | 6004C | 6005C | 6010C | 6012C | 6020C | 6030C |
| Flange size (□) | | 130 | | | | | 180 |
| Rated output (W) | | 300 | 600 | 900 | 1200 | 2000 | 3000 |
| Rated torque | (N·m) | 2.84 | 5.68 | 8.62 | 11.5 | 19.1 | 28.4 |
| | (kgf·cm) | 29 | 58 | 88 | 117 | 195 | 290 |
| Maximum instantaneous torque | (N·m) | 8.7 | 16.5 | 23.0 | 34.4 | 57.3 | 78.7 |
| | (kgf·cm) | 90 | 169 | 235 | 351 | 585 | 803 |
| Rated rpm (r/min) | | 1000 | | | | | |
| Maximum rpm (r/min) | | 2000 | | | | | |
| Rotor inertia (= $GD^2/4$) | (gf·cm·s ²) | 10.5 | 15.5 | 25.3 | 65.3 | 100.5 | 159.1 |
| | (kg·m ² × 10 ⁻⁴) | 10.3 | 15.2 | 24.8 | 64.0 | 98.5 | 156 |
| Allowable load inertia Ratio(Versus rotor) | | Not exceeding 10 times | | | | | |
| Rated power rate (kW/s) | | 7.85 | 21.3 | 30.0 | 20.5 | 37.0 | 51.8 |
| Detector type | Standard | Incremental 2000 | | | | | |
| | Option | Absolute 11/13bit 2048P/rev | | | | | |
| Weight (kg) | | 8.2 | 11.6 | 15.8 | 17.2 | 27.4 | 38.3 |

Speed and Torque Characteristics

A : Continuous duty zone & B : Intermittent duty zone



3. Wiring and Signals




Note 1) NF is an abbreviation for Noise Filter. Use this to prevent infiltration of noise from external sources.

Note 2) For FDA6005C-75C type, connect single-phase AC220 [V] to the r and t terminals of the spare power supply. FDA6001C-4C type is not provided with r and t terminals.

Note 3) Use CN1 earth cable to ground the F.G. (Frame Ground) terminals.

3.1 Power parts wiring




Note 1) NF is an abbreviation for Noise Filter. Use this to prevent infiltration of noise from external sources.


Note 2) For FDA6005C-75C type, connect single-phase AC220[V] to the **r** and **t** terminals of spare power supply.

FDA6001C-4C type is not provided with the **r** and **t** terminals.

3.1.1 Main circuit terminal board wiring




Open the main circuit terminal board cover to see the terminal board. Terminal names are located on the right side of the terminal board. (See figure on the left side.)



[FDA6005C~6012C□ Main circuit terminal]

[FDA6015C~6045C□ Main circuit terminal]



[FDA6075C□ Main circuit terminal]


1. Uses and wiring methods of FDA6001C□~6004C□ are as follows.

- 1) The R, S and T terminals are used to connect main power supply of 3-phase AC 200~230 [V] to the power circuits.
(Note) Single-phase AC 220V may also be used; however, output may be lower than the rated value. Install over current breaker on the main power supply input unit. Also, install noise filter on the power supply input terminal to shut off noise coming from the power lines.
- 2) Connect regenerative resistor between P and B terminals. The standard regenerative resistor (See Table 3.1) is a standard item. (Install it on the electric panel.)
- 3) Connect the U, V and W phases of the servo motor to the U, V and W terminals.
- 4) Ground the terminal. Also connect the servo motor earth cable to this terminal.

[Table 3.1. Recommended parts to be installed on electric panel]

| AC Servo drive system | FDA6001C□ | FDA6002C□ | FDA6004C□ |
|---|---|-----------|-----------|
| Wire thickness | AWG #16 (1.25 mm ²) | | |
| Terminal in drive system | KET GP110012 (Maker : http://www.ket.com) | | |
| Switch | GMC - 12 (13A) or equivalent (Maker : http://www.lgis.biz) | | |
| Breaker | ABS 33b (5A) or equivalent (Maker : http://www.lgis.biz) | | |
| Noise filter | NFS 305 or NFS 310 (Maker : http://www.samilemc.com) | | |
| Standard regenerative resistor (for P and B terminals) | 50W 50Ω (Size: Refer to external view 1) | | |

[External view 1] 50W 50Ω



Chapter 3. Wiring and Signals

2. Uses and wiring methods of FDA6005C~6150C are as follows.

1) The R, S and T terminals are used to connect main power supply of 3-phase AC 200-230[V] to the power circuits.

(Note) Single-phase AC 220V may also be used; however, output may be lower than the rated value. Install over current breaker on the main power supply input unit. Also, install noise filter on the power supply input terminal to shut off noise coming from the power lines.
FDA6012C fan power is supplied by servo drive itself, FDA6015C~FDA6045C fan power is supplied by S,T terminals in three phase R,S,T and FDA6075C Fan power is supplied by r, t in auxiliary power terminals. FDA6110CN, FDA6150CN FAN power is supplied by R,T terminals in three phase R,S and T.

2) The "r" and "t" terminals are for the auxiliary power supply of the power circuit. Connect single phase AC 200-230 [V] to these terminals.

3) Connect regenerative resistor between P and B terminals.

The standard regenerated resistance (See Table 3.2) is a standard item. (Install it on the electric panel)

4) Connect the U, V and W phases of the servo motor to the U, V and W terminals.

5) Ground the terminal. Also connect the servo motor earth cable to this terminal.


[Table 3.2. Recommended parts to be installed on electric panel]

| AC SERVO Drive system | FDA 6005C | FDA 6010C | FDA 6012C | FDA 6015C | FDA 6020C | FDA 6030C | FDA 6045C | FDA 6075CN | FDA 6110CN | FDA 6150CN |
|---|---|----------------------------------|--|----------------------------------|----------------------------------|------------------------------|---------------------------------------|-----------------------------------|------------------------------------|------------------------------------|
| Wire thickness | AWG #14 (2.0mm ²) | AWG #12 (3.5mm ²) | | | AWG #10 (5.5mm ²) | | AWG #8 (8.0mm ²) | AWG #6 (14.0mm ²) | AWG #4 (22.0mm ²) | |
| Drive system side press terminal | KET GP110012 | KET GP110721 | | | KET GP110027 | | JOR8-6 (KS C2620) | JOR8-14 (KS C2620) | JOR8-22 (KS C2620) | |
| Switch | GMC- 12(13A) or equivalent | GMC-22(20A) or equivalent | | GMC-40(35A) or equivalent | | GMC-65(65A) or equivalent | | GMC-85(80A) or equivalent | | GMC- 100(100A) or equivalent |
| Breaker | ABS33b (5A) or equivalent | ABS33b (10A) or equivalent | | ABS33b (20A) or equivalent | ABS33b (30A) or equivalent | | ABS53b (50A) or equivalent | ABS63b (60A) or equivalent | ABS103b (100A) or equivalent | |
| Noise Filter | NFS-4030SG | | | | | NFZ- 4040SG | NFZ- 4050SG | NFZ- 4060SG | NFZ- 4080SG | |
| Standard regenerative resistor (for P and B terminals) Size | 150W 50Ω | | 250W 25Ω | 250W 25Ω 2 units in parallel | | | 250W 25Ω 4 units in parallel | 800W 8Ω 2 units in parallel | 1Kw 6Ω 2 units in parallel | |
| | L1=172, L2=188, W=41, H=22, A=4.3, B=4.3 | | L1=220, L2=239, W=60, H=30, A=5.3, B=5.3 | | | | | | | |
| | See external view 2 | | | | | | See external view 3 | See external view 4 | | |


[Recommended Maker]

- * Terminal : <http://www.ket.com>
- * Switch, Breaker : <http://www.lgis.biz>
- * Noise Filter : <http://www.samilemc.com>


[External view 2] 150W / 250W



[External view 3] 250W*4 (FDA6075C)



[External view 4] 1600W*4 (FDA6110CN), 2000W*3 (FDA6150CN)



3.1.2 Turning ON/Off of power supply


As the main circuit of the servo drive is designed in condenser input type, high charging current (charging time approximately 03-0.5 seconds) flows when main power is connected. If the main power supply is turned ON/OFF frequently, the main circuit element may be deteriorated leading to an error. Use SVONEN (CN1-15) terminal and Stop (CN1-38) terminal to start or stop the motor.

(Caution!)

- 1) It takes approximately 1-2 seconds before Alarm signal is activated after power is connected.
Press power switch for at least 2 seconds or longer.
- 2) If the main power is connected immediately after power is shut off, Power Fail (AL-04) alarm may occur. Connect power at least 10 seconds after the power is turned off.
- 3) The above wiring diagram shows that only the main power is turned off when alarm occurs and you can check the details of the alarm.

3.1.3 Timing diagram at the time of power connection


Power is supplied to the control circuit, if single-phase power is connected to the r and t terminals. Servo becomes RDY after maximum 3s, the time required to initialize the inside of the drive system; and if the servo drive signal is turned on, operation starts 25 ms later.




3.1.4 Timing diagram at the time of Alarm occurrence

If Alarm occurs on the drive system, PWM is shut off and the motor stops.

(Caution!) Check and remove causes of Alarm and turn off the servo motor drive command (SVONEN) before resetting Alarm.




3.1.5 Timing diagram in operation



3.2 Connection and signal-form of input/output

3.2.1 Input contact signal

Function of each input contact signal is shown on the following table. The input contacts are classified into A contact and B contact depending on the contact characteristics. Check before use. Connect external power supply greater than DC +24 [V], 1 [A] to the +24 [V] power input terminal (CN1-49) to use the contact input.



Input contactor wiring(example)

| Pin number (No.) | Signal function in controlling position | Contact Type |
|----------------------|---|--|
| COMSEL0 (18) | Position Command selection 0 | ON=1, OFF=0 |
| COMSEL1 (43) | Position Command selection 1 | Select thirty two position CMD |
| COMSEL2/CCWJOG (17) | Position Command selection 2 /CCWJOG | In the case of MPG_SEL(P8-06)=1, MPGEN signal : ON => Pulse command operation |
| COMSEL3/CWJOG (42) | Position Command selection 3 /CWJOG | In the case of P8-03=2, CCWJOG/CWJOG operation(17,42) |
| COMSEL4/MPGEN (16) | Position Command selection 4/MPGEN | |
| START (41) | Start Command | ON = Starting operation |
| SVONEN (15) | Enable to servo operation | ON = Servo drive enable |
| CCWLIM/JOG (40) | Not CW/ CW Jog | OFF = Not CW/CW Jog |
| CWLIM/JOG (14) | Not CCW/ CCW Jog | OFF = Not CCW/CCW Jog |
| ORG-DOG/ORG-RET (39) | Origin DOG switch | If P8-07=0 & ON, Dog switch range If P8-07=1 & ON, Origin Return |
| ORGCOM (13) | Origin Command | ON = Origin operation |
| ALMRST.STOP (38) | ALARM RESET/ Motor stop | ON = ALARM REST ON = Motor stop |

Note 1) ON : Application contact connected to " GND24"

OFF : Application contact connected to "+24V", or applicable contact not connected.


Note 2) ALARM RESET do necessarily after servo drive ENABLE(SVOEN) signal OFF.

Note 3) If we select CW/CCW Jog function(P8-03:LIM_SEL:1), cannot use CW disable/CCW disable function.

Note 4) If we select CW/CCW Jog function(P8-03:LIM_SEL:2), can simultaneously use both CW disable/CCW disable function and CCWJOG(17)/CWJOG(42) function.

3.2.2 Output contact signal

The output contact signal functions are shown on the following table. The output contact internally uses transistor switch. Take precaution because overvoltage or overcurrent may cause damage to the system. (Power supply: DC +24 [V] ± 10%). Brake signal is used to drive the brake installed inside the motor. The sequence must be configured so when this output is turned on, power is supplied to the brake and the break is released. Other signals are the outputs which indicate the status of the drive system and the motor. Each function is shown on the following table.



Output contactor wiring(example)

(note) M1 is external relay for the brake.

| Pin number (No.) | Signal function in controlling position | Contact Type |
|-------------------------|--|--|
| ORGOUT (48) | Completion of origin reach | ON= Completion |
| RDY (22) | Servo READY | ON = READY |
| BRAKE (47) | BRAKE operation | ON = BRAKE cancellation OFF = BRAKE operation |
| ALARM (21) | ALARM | OFF = Alarm status |
| INPOS/OP0 (46) | Completion of position reach /position0 | ON = Completion |
| OP1 (20) | Position 1(Turret Mode) | ON = Completion |
| OP2 (45) | Position 2(Turret Mode) | ON = Completion |
| OP3 (19) | Position 3(Turret Mode) | ON = Completion |
| OP4 (44) | Position 4(Turret Mode) | ON = Completion |

Note 1) ON : Application contact connected to "GND24"

OFF : Application contact connected to "+24V", or applicable contact not connected.


3.2.3 Position command pulse input signal

To use the drive in position MPG mode, input the position command pulse by using the open collector input, line drive input, and pulse output of the MPG (Manual Pulse Generator) or PLC position control card using external power supply of 5 [V] and 24 [V]. The types of pulses that can be used are "direction + pulse", "forward pulse + reverse pulse", and "LEAD pulse + LAG pulse". Select the type of pulse from the Pulse Logic (P4-04) menu of the front operation panel Position Mode (P4--) menu

Photo-coupler has been used in the pulse input circuit to insulate the internal control unit of the drive system from the external pulse signal. However, if 5 [V] is used as the open collector input, connect 1/2W 150Ω resistance, or 1/2W 1.5kΩ resistance if 24 [V] is used.

| Pin No (CN1-) | PPRIN (9) | PRIN (12) | PPFIN (11) | PFIN (10) |
|------------------------|--------------------|--------------------|---------------------|--------------------|
| Signal function | + 5VA | R pulse input | + 5VA | F pulse input |

*(Caution!)connect 1/2W 1.5kΩ if 24V power is used



* In case of open collector input

* In case of line driver input

[Position command pulse application circuit(example)]

3.2.4 Analog I/O signal


Analog signal is based on 0 [V] (GND terminal) of the control power supply. Connect the GND terminal of the circuit connected to this signal with the GND terminal of CN1. The analog speed command input (CN1-27) runs the motor at a speed determined from the 10V Speed [RPM] (P3-16) menu of Speed Mode (P3-). Regardless of input voltage polarity, only plus value is applied.

To wire analog signals, connect GND wire with the signal wire by twisting them using twist pair wire in order to minimize noise. Functions of each analog signal are as follows.


| Pin Name | SPDIN (27) | MONIT1 (3) | MONIT2 (2) |
|-----------------|--------------------------------------|--|--|
| Signal function | Speed command -10 ~ +10 [V] input | Monitor output 1 -4 ~ +4 [V] output | Monitor output 2 -4 ~ +4 [V] output |

Analog signal is based on GND signal, and produces ± 12 [V] power just in case speed commands are applied through the use of variable resistance. The output capacity of this power supply is 30 [mA] at maximum. Do not exceed the maximum capacity. The power supply pin array is shown on the following table.

| Pin Name | + 12 V (35) | - 12 V (37) | GND (1,8,26,33,34,36) |
|-----------------|---------------|---------------|-----------------------|
| Signal function | + 12 [V] | - 12 [V] | 0 [V] |



[Analog signal connection]




[Using the internal power for the analog command]

3.2.5 Encoder output signal

The encoder signal is produced based on 0 [V] (GND) of control power supply. Connect 0 [V] terminal of the circuit which receives this signal from the master control system to the GND terminal of CN1. Encoder signal is produced in line driver system after the AC servo motor encoder signal received from CN2 is divided according to the frequency dividing ratio set by the sub-menu Pulse Out Rate (P2-06) of the main menu Control Mode (P2-). Function of each signal is as follows.

| Signal function | A phase output | B phase output | Z phase output |
|-----------------|----------------|----------------|----------------|
| PIN No(CN1-) | PAO(7)/PAO(32) | PBO(6)/PBO(31) | PZO(5)/PZO(30) |



[Encoder signal connection example]

3.3 CN1 Wiring and Signal

3.3.1 CN1 Wiring and Signal

| Signal | Title | Pin No. | Function |
|---------------------------------|------------------|---------|---|
| Start Command | START | 41 | Start operation (OFF → ON: Operation) |
| Origin Command | ORGCOM | 13 | Use to set origin of machine(ON: Origin command) |
| CW unable /CW Jog | CCWLIM/ CCWJOG | 40 | Parameter set at LIM_SEL(P8-03) (0:Rotation Unable, 1: Jog) OFF: Rotation Unable /Jog operation ON : Rotation Able /Jog Stop |
| CCW unable /CCW Jog | CWLIM/ CWJOG | | |
| Alarm reset /Motor stop | ALMRST/ STOP | 38 | Alarm state : Reset Alarm Normal Operation : Motor stop (maintain stop torque when this) |
| Origin switch | ORG-DOG/ ORG-RET | 39 | If P8-07=1 and DOG switch signal is ON, Origin Return operation is executed.(Only P8-01=0) In the case of Origin operation, Origin Return operation is not executed. |
| Servo Motor Operation Command | SVONEN | 15 | Determines whether servo motor can be started (ON: can start, OFF : cannot start) |
| Position command select 0 | COMSEL0 | 18 | Set internal position command(0-31) by combining five signal [LIM-SEL(P8-03)] = 0 : CCWLIM, CWLIM function 1 : CCWJOG, CWJOG function 2 : CCWLIM, CWLIM, CCWJOG, CWJOG function |
| Position command select 1 | COMSEL1 | 43 | |
| Position command select 2 | COMSEL2/ CCWJOG | 17 | |
| Position command select 3 | COMSEL3/ CWJOG | 42 | |
| Position command select 4/MPGEN | COMSEL4 /MPGEN | 16 | [MPG-SEL(P8-10)] = 0 : Select position command 4 1 : Select MPG operation Enable |

| | | | |
|--|---------------|----|---|
| +24[V] Power Input | +24VIN | 49 | Connect greater than (+24[VDC]±10% 1.0[A]) of external power supply. * Note) If used as I/O contact power supply simultaneously, recalculate the power supply capacity according to the number of output points. |
| +24[V] GND Input | GND24 | 24 | Connect GND of external power supply |
| | | 25 | |
| BRAKE Drive Output | BRAKE | 47 | This is the output signal intended to drive internal brake of motor * See [Break SPD(P2-08)], [Brake time (P2-09)] |
| READY State Output | RDY | 22 | This is No Alarm, Power Good status when power is turned ON.. |
| Position decision completion /Position 0 | INPOS/ OP0 | 46 | Display approach position CMD_Position [0-31] in position completion signal in case of absolute position operation |
| Position 1 | OP1 | 20 | Display position decision completion signal(INPOS) output in case of relative position/sequence operation |
| Position 2 | OP2 | 45 | |
| Position 3 | OP3 | 19 | |
| Position 4 | OP4 | 44 | [In Position Type(P8-08)]=0 : OP0~OP4Output 1 : INPOS Output |
| Alarm state | ALARM | 21 | Turn OFF if alarm is detected (Turn ON during normal operation) |
| Origin reach completion | ORGOUT | 48 | Turn ON when reach origin, |
| FRAME GROUND | FG | 50 | Connects earth cable of CN1. |
| Encoder Output | PAO | 7 | Outputs the encoder signal of motor in line drive system after driving it according to the frequency dividing ratio set by the parameter [Pulse out rate(P2-06)] |
| | /PAO | 32 | |
| | PBO | 6 | |
| | /PBO | 31 | |
| | PZO | 5 | |
| | /PZO | 30 | |
| Analog Speed Command (Override) | SPDIN | 27 | If we input speed command in analog voltage of the ratio set by parameter [10V Speed(P3-16)], speed override function operates. |

Chapter 3. Wiring and Signals

| | | | |
|------------------|--------|----|--|
| Monitor Output 1 | MONIT1 | 3 | Outputs within the range of -4 ~ +4 [V] according to values set to [Monitor1 Select (P2-10)], [Monitor1 ABS (P2-11)], [Monitor1 Scale (P2-12)], [Monitor1 offset (P2-13)]. [Monitor1 Select] - 0: current position, 1: position error, 2: speed, 3: torque |
| Monitor Output 2 | MONIT2 | 2 | Outputs within the range of -4 ~ +4 [V] according to values set to [Monitor2 Select (P2-14)], [Monitor2 ABS (P2-15)], [Monitor2 Scale (P2-16)], and [Monitor2 offset (P2-17)]. [Monitor2 Select]- 0: current position, 1: position error, 2: speed, 3: torque |
| +12[V] Output | +12V | 35 | Output ±12[V] used only when speed override command is simply applied. |
| -12[V]Output | -12V | 37 | |
| 0[V] | GND | 1 | This is the power supply common Ground Terminal for analog speed Override Command, positive speed monitor output, and encoder output terminals. |
| | | 8 | |
| | | 26 | |
| | | 33 | |
| | | 34 | |
| | | 36 | |
| FPulse | PPFIN | 11 | Set pulse forms according to the set value of the parameter [Pulse Logic(P4-4)]Pulse form ①Direction + Pulse ②CW Pulse + CCW Pulse ③Two phase pulse(Phase A + Phase B) |
| | PFIN | 10 | |
| RPulse | PPRIN | 9 | |
| | PRIN | 12 | |

3.3.2 CN1 pin arrangement

CN1 is the connector located at the right lower part of the front of drive system. This connector is used to connect the drive system with the master control system which commands the operation.


The figure on the right side shows the pin array of the connector CN1 seen from the user side connector.

(Note 1) CN1 connector is an option item.

* Maker: 3M


* Case name: 10350-52FO-008

*Connector (For soldering): 10150-3000VE




PIN Array of CN1
(Based on the soldered side of the user connector)


3.3.3 Absolute coordinate operation mode CN1 wiring



3.3.4 Relative coordinate operation mode CN1 wiring



3.3.5 Sequence operation mode CN1 wiring




3.4 Description of CN2 Wiring and Signals

3.4.1 Wiring and signals of incremental encoder

CN2 is a connector located in the right center of the front part of the drive system. This is used to connect the drive system and servo motor encoder.

The right figure shows pin array viewed from the user connector. Encoder signal varies slightly according to the type of encoder.



PIN array of CN2

[Based on the soldered side
of the user connector]

Wiring of CN2 and the FMA-CN series AC servo motor's incremental encoder is shown on the following table.


| CN2 pin No. | Signal name | Motor (□60, 80 series) side encoder connector pin No. | Motor (□130, 180 series) side encoder connector pin No. |
|-------------|--------------|--|--|
| 1 | PW | 11 | P |
| 2 | /PW | 12 | R |
| 3 | PV | 9 | M |
| 4 | /PV | 10 | N |
| 5 | PU | 7 | K |
| 6 | /PU | 8 | L |
| 7 | | | |
| 8 | | | |
| 9 | GND | 14 | G |
| 10 | | | |
| 11 | /PZ | 6 | F |
| 12 | F.G. | 15 | J |
| 13 | /PB | 4 | D |
| 14 | PZ | 5 | E |
| 15 | /PA | 2 | B |
| 16 | PB | 3 | C |
| 17 | | | |
| 18 | PA | 1 | A |
| 19 | Vcc(DC 5V) | 13 | H |
| 20 | | | |

(Caution!) Connect the earth cable of the encoder wiring to F.G.


(Caution!) Cable specifications:

- AWG24 or AWG26 x 9 pair twist, shield cable (maximum length: 20 m)
- COVV(LS Cable) or equivalent

[Example of wiring between motor side (□60, □80 series) and FDA6000C CN2 when incremental encoder is used]



[Example of wiring between motor side (□130, □180 series) and FDA6000C CN2 when incremental encoder is used]




[CN2 wiring diagram]

3.4.2 Wiring diagram of CN2 using absolute encoder

CN2 is a connector located in the right center of the front part of the drive system. This is used to connect the drive system and servo motor encoder.

The right figure shows pin array viewed from the user connector. Encoder signal varies slightly according to the types of encoder.



PIN array of CN2

Based on the soldered side of the user connector)

Chapter 3. Wiring and Signals

(Note) CN2 connector is an option item.

- * Maker: 3M
- * Case product name: 10320-52FO-008
- * Connector (For soldering): 10120-3000VE


Wiring between CN2 and the FMA-series AC servo motor absolute encoder is shown on the following table.

| CN2 pin No. | Signal name | Motor side encoder connector pin No. | |
|-------------|--------------|--------------------------------------|------------------|
| | | □60, 80 series | □130, 180 series |
| 1 | RX | 11 | P |
| 2 | /RX | 12 | R |
| 3 | | | |
| 4 | | | |
| 5 | | | |
| 6 | | | |
| 7 | BAT+ | 9 | K |
| 8 | BAT- | 10 | L |
| 9 | GND | 14 | G |
| 10 | | | |
| 11 | /PZ | 6 | F |
| 12 | F.G. | 8 | N |
| 13 | /PB | 4 | D |
| 14 | PZ | 5 | E |
| 15 | /PA | 2 | B |
| 16 | PB | 3 | C |
| 17 | | | |
| 18 | PA | 1 | A |
| 19 | Vcc(DC 5V) | 13 | H |
| 20 | ERST | 7 | M |

* Connect the earth cable of the encoder wiring to F.G.


* Cable specifications: AWG24 x 9 pair twist, shield cable (maximum length: 20 m)

Press the encoder Reset switch connected between the encoder reset terminal ERST (CN2-20) and the Vcc terminal (CN2-19) for longer than 4 seconds to set the zero point of the absolute encoder itself or in case of alarm.




[Wiring of encoder reset switch]

[Example of wiring between motor side (□60, 80 series) and FDA6000CA CN2 when absolute encoder is used]



[CN2 Wiring diagram]

[Example of wiring between motor side (□130, 180 series) and FDA6000CA CN2 when absolute encoder is used]




[CN2 wiring diagram]

4. Digital Loader Operation

Prior to turning ON the servo enable, check the parameters [Motor parameters (P1--)] related to the motor at the digital loader. In order for the servo system to operate satisfactorily based on the information on the motor connected to the servo, accurate value must be set.


Next, monitor [Status Window (St--)] and verify that all commands and limit values are properly set.

For initial operation, verify certain degree of stability through auto-tuning and trial operation (jog, simulation). Auto-tuning can be achieved through on-line system, but it is not necessary to use this function in case stabilized control gain is acquired through off-line system.



[External view of digital loader]

4.1 Handling and Menu system




4.2 Changing Parameters


The parameter value can be changed in the same method.


Even though the changeable range varies according to menu, operation methods are the same. Hence, [Motor ID (P1-01)] is presented here as a representative example.

 PROG Starts parameter editing and cancels parameter change

 ENTER Confirm changed parameter

 Increases or decreases cursor position value

 Moves cursor to left or right



5. Parameter Setting

Menus can be set by the digital loader. See Chapter 4 for information on how to use the digital loader.

Abbreviations used in this manual and their meanings are as follows.

| Abbreviation | Meaning | Abbreviation | Meaning |
|--------------|---------------------|--------------|---------------|
| PC | Position Controller | ACCEL | Acceleration |
| SC | Speed Controller | DECEL | Deceleration |
| LMT | Limit | VOLT | Voltage |
| rpm | r/min | SPD | Speed |
| ms | msec | OFFS | Offset |
| μs | μsec | TC | Time Constant |
| FRQ | Frequency | FF | Feedforward |
| FLT | Filter | FB | Feedback |
| ENB | Enable | ERR | Error |
| INIT | Initialize | FLLW | Follow |
| DFLT | Default | ELCTR | Electric |
| PROG | Program | NUM | Numerator |
| CMD | Command | DEN | Denominator |

5.1 Parameter Summary

Digital loader displays menus along with menu names.

(1) Status window (Status window: St--)

| Menu | Menu title | Description | Unit | Display range | Default |
|-------|------------------|------------------|------|------------------|---------|
| St-01 | CMD Position | Position Command | User | -99999.9~99999.9 | 0 |
| St-02 | Current Position | Current Position | User | -99999.9~99999.9 | 0 |
| St-03 | Position Error | Position Error | User | -99999.9~99999.9 | 0 |
| St-04 | Motor Speed[rpm] | Motor Speed | rpm | -9999.9~9999.9 | 0 |
| St-05 | Limit Speed[rpm] | Command Speed | rpm | -9999.9~9999.9 | 0 |
| St-06 | Torque Limit[%] | Torque Limit | % | 0 ~ 999 | 300 |
| St-07 | Load Rate[%] | Load Ratio | % | -99999 ~ 99999 | 0 |
| St-08 | Max Load Rate[%] | Max. Load Ratio | % | -99999 ~ 99999 | 0 |
| St-09 | Program Version | Program Version | | | Ver. |
| St-10 | I/O Status | I/O Status | | | |

(2) Motor and system parameter (Motor parameters: P1--)

| Menu | Menu title | Description | Unit | Range | Default |
|---------|------------------|-----------------|------------------------|----------------|----------|
| * P1-01 | Motor ID | ID | | 0 ~ 99 | |
| * P1-02 | JM [gfcms2] | Inertia | gf-cm-sec ² | 0.01 ~ 999.99 | |
| * P1-03 | KT [kgfcm/A] | Torque Constant | kgf-cm/A | 0.001 ~ 999.99 | |
| * P1-04 | Ls(Phase)[mH] | Inductance | mH | 0.001 ~ 999.99 | |
| * P1-05 | Rs(Phase)[Ω] | Resistance | Ω | 0.001 ~ 999.99 | |
| * P1-06 | Is(Rated)[Arms] | Rated Current | A (rms) | 0.01 ~ 999.99 | |
| * P1-07 | SPD(Max)[rpm] | Max. SPD | rpm | 0.1 ~ 9999.9 | |
| * P1-08 | SPD(Rated)[rpm] | Rated SPD | rpm | 0.1 ~ 9999.9 | |
| * P1-09 | Pole Number | | pole | 2 ~ 98 | 8 |
| * P1-10 | Power Amp Type | | | 0 ~ 20 | Capacity |
| * P1-11 | Encoder Type | | | 0 ~ 9 | 0 |
| * P1-12 | Encoder PLS[PPR] | Pulse/rev. | ppr | 1 ~ 10000 | 2000 |
| *P1-13 | Parameter Lock | | | 0, 1 | 0 |
| P1-14 | Slave ID | | | 1 ~ 31 | 1 |
| *P1-15 | I/O Input Type | | | 0, 1 | 0 |

(Caution !) Menus marked with "*" cannot be corrected during Servo-ON.

(3) Control parameter (Control mode: P2--)

| Menu | Menu title | Description | Unit | Display range | Default |
|-------|-----------------|--------------------|----------|----------------|-------------------------|
| P2-01 | PC P Gain | PC Proportion Gain | rad/s | 0 ~ 500 | 50 |
| P2-02 | SC LOOP Gain | SC Proportion Gain | rad/s | 0 ~ 5000 | (Note 1) By capacity |
| P2-03 | SC I TC [ms] | Time Constant | ms | 1 ~ 10000 | (Note 2) By capacity |
| P2-04 | TRQ LMT(+) [%] | Torque Limit | % | 0 ~ 300 | 300 |
| P2-05 | TRQ LMT(-) [%] | Torque Limit | % | 0 ~ 300 | 300 |
| P2-06 | Pulse Out Rate | | division | 1 ~ 16 | 1 |
| P2-07 | Current Offset | | | 0, 1 | 0 |
| P2-08 | Brake SPD[rpm] | | rpm | 0.0 ~ 9999.9 | 50.0 |
| P2-09 | Brake Time[ms] | | ms | 0 ~ 10000 | 10 |
| P2-10 | Monitor1 Select | DA Output | | 0 ~ 2 | 0 |
| P2-11 | Monitor1 ABS | | | 0, 1 | 0 |
| P2-12 | Monitor1 Scale | | multiple | 1.00 ~ 20.00 | 1.00 |
| P2-13 | Monitor1 offset | | % | -100.0 ~ 100.0 | 0 |
| P2-14 | Monitor2 Select | DA Output | | 0 ~ 2 | 1 |
| P2-15 | Monitor2 ABS | | | 0, 1 | 0 |
| P2-16 | Monitor2 Scale | | multiple | 1.00 ~ 20.00 | 1.00 |
| P2-17 | Monitor2 offset | | % | -100.0 ~ 100.0 | 0 |

5. Parameter Setting

| | | | | | |
|---------|------------------|--|----------|-----------|-------------------------|
| P2-18 | Resonant FRQ[Hz] | | Hz | 0 ~ 1000 | 300 |
| P2-19 | Resonant BW[Hz] | | Hz | 0 ~ 1000 | 100 |
| P2-20 | De-Resonant ENB | | | 0, 1 | 0 |
| P2-21 | Inertia Ratio | | multiple | 1.0~500.0 | 1.0 |
| P2-22 | Autotune Range | | | 0~9 | 0 |
| P2-23 | Autotune ON/OFF | | | ON/OFF | OFF |
| * P2-24 | Parameter Init | | | curr/dFLT | curr |
| P2-25 | Power fail Mode | | | 0, 1 | (Note 3) By capacity |
| P2-26 | DB Control | | | 0, 1 | 1 |
| P2-27 | Display Select | | | 1~11 | 1 |
| P2-28 | Zero SPD VIB RJT | | rpm | 0.0~100.0 | 0.0 |
| P2-29 | Confirm ON/OFF | | | ON/OFF | ON |

(Note 1) Default value of SC Loop gain by capacity - FDA6001C-4C: 500, FDA6005C-150CN: 200

(Note 2) Default value of SC TC[ms] by capacity - FDA6001C-4C: 20, FDA6005C-150CN: 50

(Note 3) Default value of Powerfail Mode by capacity - FDA6001C-4C: 0, FDA6005C-150CN: 1

(Caution !) Menus marked with "*" cannot be corrected during Servo-ON.

(4) Speed control parameter (Speed Mode: P3--)

| Menu | Menu title | Description | Unit | Range | Default |
|---------|------------------|-------------------------|------|--------------|---------|
| P3-01 | Group SPD0 [rpm] | Group speed0 | rpm | 0 ~ 9999.9 | 100 |
| P3-02 | Group SPD1 [rpm] | Group speed1 | rpm | 0 ~ 9999.9 | 500 |
| P3-03 | Group SPD2 [rpm] | Group speed2 | rpm | 0 ~ 9999.9 | 1000 |
| P3-04 | Group SPD3 [rpm] | Group speed3 | rpm | 0 ~ 9999.9 | 1500 |
| P3-05 | Group ACC0 [ms] | Group0 acceleration | ms | 0 ~ 10000 | 10 |
| P3-06 | Group ACC1 [ms] | Group1 acceleration | ms | 0 ~ 10000 | 20 |
| P3-07 | Group ACC2 [ms] | Group2 acceleration | ms | 0 ~ 10000 | 30 |
| P3-08 | Group ACC3 [ms] | Group3 acceleration | ms | 0 ~ 10000 | 40 |
| P3-09 | Origin ACC [ms] | Origin/Jog acceleration | ms | 0 ~ 10000 | 10 |
| P3-10 | Group DEC0 [ms] | Group0 deceleration | ms | 0 ~ 10000 | 10 |
| P3-11 | Group DEC1 [ms] | Group1 deceleration | ms | 0 ~ 10000 | 20 |
| P3-12 | Group DEC2 [ms] | Group2 deceleration | ms | 0 ~ 10000 | 30 |
| P3-13 | Group DEC3 [ms] | Group3 deceleration | ms | 0 ~ 10000 | 40 |
| P3-14 | Origin DEC [ms] | Origin/Jog deceleration | ms | 0 ~ 10000 | 10 |
| * P3-15 | FDELAY [ms] | Speed trajectory delay | ms | 0.0 ~ 100.0 | 0 |
| * P3-16 | 10V Speed[rpm] | 10V speed | rpm | 0 ~ 9999.9 | 0 |
| P3-17 | Zero Clamp Mode | ZERO Clamp mode | | 0 ~ 2 | 0 |
| P3-18 | Clamp VOLT[mV] | Clamp voltage | mV | -1000 ~ 1000 | 0 |

(Caution !) Menus marked with "*" cannot be corrected during Servo-ON.

(5) Position control parameter (Position Mode: P4--)

| Menu | Menu title | Description | Unit | Range | Default |
|-------------|-------------------|---------------------------------------|-------------|------------------|----------------|
| P4-01 | Feedforward[%] | Feedforward Gain | % | 0 ~ 100 | 0 |
| P4-02 | In Position | Position decision range | USER | 0.001 ~999.999 | 0.1 |
| P4-03 | Following Error | Error and range | USER | -99999.9~99999.9 | 90000 |
| * P4-04 | Pulse Logic | Select Command Pulse forms | | 0 ~ 5 | 0 |
| P4-05 | FF FLT TC[ms] | Feedforward filter time constant | ms | 0 ~ 10000 | 0 |
| P4-06 | S-Type TC[ms] | Position command filter time constant | ms | 0 ~ 10000 | 0 |

(Caution !) Menus marked with "*" cannot be corrected during Servo-ON.

(6) Position command parameter (POS Command Mode: P5--)

| Menu | Menu title | Description | Unit | Range | Default |
|-------------|-------------------|---------------------|-------------|------------------|----------------|
| P5-01 | Position CMD0 | position command 0 | USER | -99999.9~99999.9 | 10 |
| P5-02 | Position CMD1 | position command 1 | USER | -99999.9~99999.9 | 20 |
| P5-03 | Position CMD2 | position command 2 | USER | -99999.9~99999.9 | 30 |
| P5-04 | Position CMD3 | position command 3 | USER | -99999.9~99999.9 | 40 |
| P5-05 | Position CMD4 | position command 4 | USER | -99999.9~99999.9 | 50 |
| P5-06 | Position CMD5 | position command 5 | USER | -99999.9~99999.9 | 60 |
| P5-07 | Position CMD6 | position command 6 | USER | -99999.9~99999.9 | 70 |
| P5-08 | Position CMD7 | position command 7 | USER | -99999.9~99999.9 | 80 |
| P5-09 | Position CMD8 | position command 8 | USER | -99999.9~99999.9 | 90 |
| P5-10 | Position CMD9 | position command 9 | USER | -99999.9~99999.9 | 100 |
| P5-11 | Position CMD10 | position command 10 | USER | -99999.9~99999.9 | 110 |
| P5-12 | Position CMD11 | position command 11 | USER | -99999.9~99999.9 | 120 |
| P5-13 | Position CMD12 | position command 12 | USER | -99999.9~99999.9 | 130 |
| P5-14 | Position CMD13 | position command 13 | USER | -99999.9~99999.9 | 140 |
| P5-15 | Position CMD14 | position command 14 | USER | -99999.9~99999.9 | 150 |
| P5-16 | Position CMD15 | position command 15 | USER | -99999.9~99999.9 | 160 |
| P5-17 | Position CMD16 | position command 16 | USER | -99999.9~99999.9 | 170 |
| P5-18 | Position CMD17 | position command 17 | USER | -99999.9~99999.9 | 180 |
| P5-19 | Position CMD18 | position command 18 | USER | -99999.9~99999.9 | 190 |
| P5-20 | Position CMD19 | position command 19 | USER | -99999.9~99999.9 | 200 |
| P5-21 | Position CMD20 | position command 20 | USER | -99999.9~99999.9 | 210 |
| P5-22 | Position CMD21 | position command 21 | USER | -99999.9~99999.9 | 220 |
| P5-23 | Position CMD22 | position command 22 | USER | -99999.9~99999.9 | 230 |
| P5-24 | Position CMD23 | position command 23 | USER | -99999.9~99999.9 | 240 |
| P5-25 | Position CMD24 | position command 24 | USER | -99999.9~99999.9 | 250 |
| P5-26 | Position CMD25 | position command 25 | USER | -99999.9~99999.9 | 260 |
| P5-27 | Position CMD26 | position command 26 | USER | -99999.9~99999.9 | 270 |
| P5-28 | Position CMD27 | position command 27 | USER | -99999.9~99999.9 | 280 |
| P5-29 | Position CMD28 | position command 28 | USER | -99999.9~99999.9 | 290 |
| P5-30 | Position CMD29 | position command 29 | USER | -99999.9~99999.9 | 300 |
| P5-31 | Position CMD30 | position command 30 | USER | -99999.9~99999.9 | 310 |
| P5-32 | Position CMD31 | position command 31 | USER | -99999.9~99999.9 | 320 |

5. Parameter Setting

(7) Jog/Original mode parameter (Jog/Origin Mode: P6--)

| Menu | Menu title | Description | Unit | Range | Default |
|-------|------------------|--------------------------------------|------|------------------|---------|
| P6-01 | Origin SPD0[rpm] | Origin operation speed 0 | rpm | 0.0 ~ 9999.9 | 50 |
| P6-02 | Origin SPD1[rpm] | Origin operation speed 1 | rpm | 0.0 ~ 9999.9 | 10 |
| P6-03 | Origin Torque[%] | Damper Origin Torque | % | 0.0 ~ 300 | 50 |
| P6-04 | Origin Offset | Coordinates value of Origin Position | USER | -9999.9 ~ 9999.9 | 0 |
| P6-05 | Jog Speed0[rpm] | Jog Operation speed 0 | rpm | 0.0 ~ 9999.9 | 100 |
| P6-06 | Jog Speed1[rpm] | Jog Operation speed 1 | rpm | 0.0 ~ 9999.9 | 200 |
| P6-07 | INC Jog Value0 | INC Jog Movement quantity 0 | USER | 0.0 ~ 99999.9 | 50 |
| P6-08 | INC Jog Value1 | INC Jog Movement quantity 1 | USER | 0.0 ~ 99999.9 | 100 |

(8) Mechanical mode parameter (Mechanical Mode: P7--)

| Menu | Menu title | Description | Unit | Range | Default |
|--------|------------------|--|-------|------------|---------|
| *P7-01 | Move Motor | Motor rotation quantity | USER | 1 ~ 50000 | 1 |
| *P7-02 | Move Mechanical | Device movement quantity | USER | 1 ~ 50000 | 100 |
| *P7-03 | Move Polarity | Movement Direction | | 0 ~ 1 | 1 |
| *P7-04 | Turret Cycle | Machinery Position per a cycle | USER | 0 ~ 50000 | 0 |
| *P7-05 | MPG Move[rev] | Motor rotation quantity | rev | 1 ~ 10000 | 1 |
| *P7-06 | MPG Pulse[pulse] | Input MPG Pulse Number | pulse | 1 ~ 100000 | 100 |
| *P7-07 | Angle Division | Angle division stop when Jog operation | USER | 0 ~ 1000 | 0 |

(Caution !) Menus marked with "*" cannot be corrected during Servo-ON.

(9) Operation mode parameter (Operation Mode: P8--)

| Menu | Menu title | Description | Unit | Range | Default |
|--------|-----------------|--------------------------------|------|------------------|----------|
| *P8-01 | Run Mode | Operation Mode | | 0 ~ 7 | 1 |
| P8-02 | Stop Time [ms] | Continuous operation stop time | ms | 0 ~ 10000 | 10 |
| *P8-03 | Limit Select | Limit↔Jog↔Limit,Jog | | 0 ~ 2 | 0 |
| *P8-04 | Soft Lim Enable | Select Soft Limit | | 0,1 | 0 |
| P8-05 | Soft CCWLim | Set CCWlim Value | USER | -99999.9~99999.9 | 99999.0 |
| P8-06 | Soft CWLim | Set CWLim Value | USER | -99999.9~99999.9 | -99999.0 |
| *P8-07 | Dog Select | Origin Return Operation | | 0,1 | 0 |
| *P8-08 | Auto Origin | Automatic Origin Operation | | 0,1 | 0 |
| *P8-09 | Origin Rule | Origin execution Method | | 0 ~ 24 | 2 |

| | | | | | |
|--------|------------------|-------------------------------------|--|----------------|---|
| *P8-10 | MPG Select | Select MPG | | 0,1 | 0 |
| *P8-11 | ABS ORG SET | Set origin of absolute type encoder | | 0,1 | 0 |
| *P8-12 | IN POSITION TYPE | IN POS Complete Signal output type | | 0,1 | 1 |
| *P8-13 | Stop select | Stop Fuction selection | | 0 ~ 2 | 0 |
| *P8-14 | Ias Offset | Save Offset value | | 99.999~99.999 | |
| *P8-15 | Ics Offset | Save Offset value | | 99.999~99.999 | |
| *P8-16 | Command abs data | Multi-Turn Data on cmd position | | 100000~-100000 | |
| *P8-17 | Current abs data | Multi-Turn Data on cur position | | 100000~-100000 | |
| *P8-18 | ABS Counter2 | Abs encoder Data | | 99999~99999 | |
| *P8-19 | ABS Counter1 | Abs encoder Data | | 99999~99999 | |
| *P8-20 | ABS Counter0 | Abs encoder Data | | 99999~99999 | |

(Caution !) Menus marked with "*" cannot be corrected during Servo-ON.

(10) Alarm status (Alarm Status: ALS--)

| Menu | Menu title | Description | Unit | Default |
|-------|-----------------|-------------------------|------|---------|
| ALS01 | Alarm Display | Alarm witch happens how | | |
| ALS02 | Alarm Reset | Now Reset ALARM | | |
| ALS03 | Alarm History | ALARM history | | |
| ALS04 | Alarm Reset All | Reset ALARM history | | |

(11) Jog Operation status (Jog Status)

If press Enter-KEY in Position CMD subordinate Mode, set Jog Mode.

| Menu | Menu title | Description | Unit | Range | Default |
|------|-------------|----------------|------|--------------------|---------|
| | JOG State0 | Loader Jog 0 | | -99999.9 ~ 99999.9 | |
| | JOG State1 | Loader Jog 1 | | -99999.9 ~ 99999.9 | |
| | IJOG State0 | Loader I_Jog 0 | | -99999.9 ~ 99999.9 | |
| | IJOG State1 | Loader I_Jog 1 | | -99999.9 ~ 99999.9 | |

5. Parameter Setting

5.2 Motor and System Parameter (Motor Parameter: P1--)

These parameters are used to set the motor and the system. User must set parameters to suit the motor and the system prior to use.

| Menu | Menu title | | Description | | Unit | Setting range | | Default | |
|--------|------------------|----|-------------|----|-------|---------------|-------|---------|-------|
| *P1-01 | Motor ID | | Motor ID | | | 0 ~ 99 | | 0 | |
| ID | Model | ID | Model | ID | Model | ID | Model | ID | Model |
| 0 | Individual input | 20 | TF05 | 40 | LF03 | 60 | KN03 | 80 | LN03 |
| 1 | | 21 | TF09 | 41 | LF06 | 61 | KN05 | 81 | LN06 |
| 2 | | 22 | TF13 | 42 | LF09 | 62 | KN06 | 82 | LN09 |
| 3 | | 23 | TF20 | 43 | LF12 | 63 | KN07 | 83 | LN12 |
| 4 | | 24 | TF30 | 44 | LF20 | 64 | KN06A | 84 | LN12A |
| 5 | CKZ5 | 25 | TF44 | 45 | LF30 | 65 | KN11 | 85 | LN20 |
| 6 | CK01 | 26 | TF09-05 | 46 | | 66 | KN16 | 86 | LN30 |
| 7 | | 27 | | 47 | | 67 | KN22 | 87 | LN40 |
| 8 | CK02 | 28 | | 48 | | 68 | KN22A | 88 | TN110 |
| 9 | CK04 | 29 | | 49 | | 69 | KN35 | 89 | TN150 |
| 10 | | 30 | KF08 | 50 | CN04A | 70 | TN05 | 90 | |
| 11 | CN01 | 31 | KF10 | 51 | CN06 | 71 | TN09 | 91 | |
| 12 | CN02 | 32 | KF15 | 52 | CN08 | 72 | TN13 | 92 | |
| 13 | CN03 | 33 | KF20 | 53 | CN10 | 73 | TN17 | 93 | |
| 14 | CN04 | 34 | KF35 | 54 | CN09 | 74 | TN20 | 94 | |
| 15 | CN05 | 35 | KF50 | 55 | CN15 | 75 | TN30 | 95 | |
| 16 | | 36 | | 56 | CN22 | 76 | TN44 | 96 | |
| 17 | | 37 | | 57 | CN30 | 77 | TN75 | 97 | |
| 18 | | 38 | | 58 | CN30A | 78 | TN55 | 98 | |
| 19 | | 39 | | 59 | CN50 | 79 | KN55 | 99 | |

| |
|---|
| If the motor used is in the above table, input motor ID to [Motor ID(P1-01)]. In such case, [JM (P1-02)], [KT (P1-03)], [Ls(Phase) (P1-04)], [Rs(Phase) (P1-05)], [Is(Rated) (P1-06)], [SPD(Max) (P1-07)], [SPD(Rated) (P1-08)], [Pole Number (P1-09)] among the set values are automatically set, and individual editing is not allowed. If the motor used is not shown on the above table, or if it is desired to change one or more of the set values related to the motor, input 0 to [Motor ID (P1-01)]. |
|---|

| Menu | Menu title | Description | Unit | Display range | Default |
|--|-------------|-------------|------------------------|---------------|---------|
| *P1-02 | JM [gfcms2] | Inertia | gf-cm-sec ² | 0.01 ~ 999.99 | |
| Convert the motor inertia moment in [gf-cm-sec ²] and input the data. | | | | | |
| In this item, input the inertia of the motor which does not include load inertia. | | | | | |
| For information on how to input load inertia, see section [Inertia Ratio (P2-21)]. | | | | | |
| Procedure of converting general unit to that of [gf-cm-sec ²] is as follows. | | | | | |
| 1[kg-cm ²] → 1.02 [gf-cm-sec ²] | | | | | |
| 1[kg-m ²] → 1.02 × 10 ⁴ [gf-cm-sec ²] | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|--|--------------|-----------------|----------|----------------|---------|
| *P1-03 | KT [kgfcm/A] | Torque Constant | kgf-cm/A | 0.001 ~ 999.99 | |
| Convert the motor torque constant in [kgf-cm/A] and input the data. | | | | | |
| Torque constant is defined in the torque level corresponding to 1[A, rms]. | | | | | |
| Procedure of converting MKS unit to that of [kgf-cm/A] is as follows. | | | | | |
| 1[N·m/A] → 10.2[kgf-cm/A] | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|--|---------------|-------------|------|----------------|---------|
| *P1-04 | Ls(Phase)[mH] | Inductance | mH | 0.001 ~ 999.99 | |
| *P1-05 | Rs(Phase)[Ω] | Resistance | Ω | 0.001 ~ 999.99 | |
| Convert the motor phase inductance in [mH] and input the data. | | | | | |
| Convert the motor phase resistance in [] and input the data. | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|--|-----------------|---------------|---------|---------------|---------|
| *P1-06 | Is(Rated)[Arms] | Rated Current | A (rms) | 0.01 ~ 999.99 | |
| Convert the motor rated current in [A] and input the data. | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|---|-----------------|-------------|------|---------------|---------|
| *P1-07 | SPD(Max)[rpm] | Max. SPD | rpm | 0.1 ~ 9999.9 | |
| *P1-08 | SPD(Rated)[rpm] | Rated SPD | rpm | 0.1 ~ 9999.9 | |
| Input motor's maximum speed and rated speed in rpm (r/min). | | | | | |

5. Parameter Setting

| Menu | Menu title | Description | Unit | Display range | Default |
|--|-------------|-------------|------|---------------|---------|
| *P1-09 | Pole Number | | Pole | 2 ~ 98 | 8 |
| Input the number of motor poles. | | | | | |
| The number of motor poles is always expressed in even number. Take caution not to input odd numbers. | | | | | |
| Our company servo motor has 8 pole numbers in all. | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default | | | | | | | |
|--|----------------|-------------|-------|---------------|-------------|-------|-------|-------|-------|--------|--------|--------|
| *P1-10 | Power Amp Type | Drive Type | | 0 ~ 20 | By capacity | | | | | | | |
| Input the following set values according to the capacity of the servo motor. | | | | | | | | | | | | |
| 6001C | 6002C | 6004C | 6005C | 6010C | 6012C | 6015C | 6020C | 6030C | 6045C | 6075CN | 6110CN | 6150CN |
| 0 | 1 | 2 | 5 | 6 | 7 | 11 | 12 | 13 | 14 | 15 | 16 | 17 |

| Menu | Menu title | Description | Unit | Display range | Default |
|---|--------------|--------------|-----------|-------------------------------|---------|
| *P1-11 | Encoder Type | Encoder Type | | 0 ~ 9 | 0 |
| The value has been set to "0" at the time of delivery based on general incremental encoder (A Lead in case of forward run). | | | | | |
| (Based on using Our company standard motor) | | | | | |
| If other encoders are used, set the value according to the following classification. | | | | | |
| Type of encoder | | | Set value | Remarks | |
| General incremental encoder | | | 0 | A lead in case of forward run | |
| General incremental encoder | | | 1 | A lead in case of forward run | |
| Sumtak 9-wire incremental encoder | | | 5 | Optional | |
| Sumtak absolute value encoder (2048p/r) | | | 6 | Optional | |

| Menu | Menu title | Description | Unit | Display range | Default |
|---|------------------|-------------|------|---------------|---------|
| *P1-12 | Encoder PLS[ppr] | Pulse/Rev. | ppr | 1 ~ 10000 | 2000 |
| Input the number of pulses on the encoder A and B phases. | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|--|----------------|---------------------|------|---------------|---------|
| *P1-13 | Parameter Lock | Edit enable/disable | | 0/1 | 0 |
| Set whether parameter locking is to be executed. | | | | | |
| 0: Parameter correction possible | | | | | |
| 1: Parameter correction not possible | | | | | |

5.3 Control Parameter (Control Mode: P2--)


| Menu | Menu title | Description | Unit | Display range | Default |
|---|------------|--------------------|-------|---------------|---------|
| P2-01 | PC P Gain | PC Proportion Gain | rad/s | 0 ~ 500 | 50 |
| If the proportional gain is large, the time to reach the command position is reduced. However, if the proportional gain is excessively large, vibration occurs when the motor stops, or overshoot occurs in transient status. | | | | | |
| Recommended set value = $\frac{[\text{SC LOOP Gain(P2-02)}]}{10}$ [rad/sec] | | | | | |
| Recommended maximum set value = $\frac{[\text{SC LOOP Gain(P2-02)}]}{4}$ [rad/sec] | | | | | |
| If the maximum set value is exceeded, overshoot may occur on the position. | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|--|--------------|--------------------|-------|---------------|-------------|
| P2-02 | SC LOOP Gain | SC Proportion Gain | rad/s | 0 ~ 5000 | By capacity |
| If the speed loop gain is large, high speed response characteristics may be obtained but the normal condition characteristics may become deteriorated. Set appropriate level of loop gain to ensure desired performance. | | | | | |
| If the ratio of the overall system inertia (Sum of motor inertia and load inertia) to the motor inertia is set in [Inertia Ratio (P2-21)], or if the value set by using the autotuning [Autotuning (P2-23)] provided with the servo is the same as the following, the recommended set values of [SC Loop Gain (P2-02)] by servo capacity are as follows. | | | | | |
| (Caution!) Default value by capacity – FDA6001C-4C: 500, FDA6005C-150CN: 200 | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|--|------------|---------------|------|---------------|-------------|
| P2-03 | SC I TC | Time Constant | ms | 1 ~ 10000 | By capacity |
| If the SC I TC value is reduced, the characteristic of steady and transient state is improving. But too much reduction brings out the overshoot of speed. So, set appropriate level of TC to ensure desired performance. If “10000” value is inputted, speed control type is “P” type. | | | | | |
| (Caution!) Default value by capacity – FDA6001C-4C: 20, FDA6005C-150CN: 50 | | | | | |
| Recommended set value = $\frac{10000}{[\text{SC LOOP Gain(P2-02)}]}$ [ms] | | | | | |
| Recommended minimum set value = $\frac{3000}{[\text{SC LOOP Gain(P2-02)}]}$ [ms] | | | | | |

5. Parameter Setting

| Menu | Menu title | Description | Unit | Display range | Default |
|--|----------------|------------------|------|---------------|---------|
| P2-04 | TRQ LMT(+) [%] | Torque Limit (+) | % | 0 ~ 300 | 300 |
| P2-05 | TRQ LMT(-) [%] | Torque Limit (-) | % | 0 ~ 300 | 300 |
| Maximum CW torque = $\frac{[TRQ\ LMT(+)\ (P2-04)]}{100} \times \text{rated torque}$ | | | | | |
| Maximum CCW torque = $\frac{[TRQ\ LMT(-)\ (P2-05)]}{100} \times \text{rated torque}$ | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|--|----------------|----------------|----------|---------------|---------|
| P2-06 | Pulse Out Rate | Division ratio | Division | 1 ~ 16 | 1 |
| Divide the A and B phase encoder pulses fed back from the motor, and set the encoder pulse dividing ratio to be output in line drive method. The allowable dividing ratio is from 1 division to 16 divisions. Input desired dividing ratio in this item. Frequency division is defined as follows. | | | | | |
|  | | | | | |
| | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|---|----------------|------------------------------------|------|---------------|---------|
| P2-07 | Current Offset | The compensation of current offset | | 0, 1 | 0 |
| Motor speed may have periodic ripple due to the effects of the servo current offset. If this happens, use the current offset function. "1" = Automatically compensates current offset during Servo-On. | | | | | |
| | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|---|----------------|----------------------|------|---------------|---------|
| P2-08 | Brake SPD[rpm] | Brake activation SPD | rpm | 0.0 ~ 9999.9 | 50.0 |
| If the servo is turned OFF during servo motor operation and the brake speed is reduced, set the speed which activates the external machine brake in rpm (r/min). The output contact (Brake) is turned OFF at this time. | | | | | |

| Menu | Menu name | Description | Unit | Display range | Default |
|---|----------------|-----------------------|------|---------------|---------|
| P2-09 | Brake Time[ms] | Brake activation Time | ms | 0 ~ 10000 | 10 |
| <p>If the servo is turned OFF during servo motor operation and the brake speed is reduced, set the time which activates the machine brake after a specific time irrespective of [Brake SPD (P2-08)] in [msec]. The output contact (Brake) is turned OFF at this time.</p> <p>If "0" is input: The machine brake is activated only by [Brake SPD (P2-08)], but is not activated according to time.</p> | | | | | |
| | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|--|-----------------|--------------|------|---------------|---------|
| P2-10 | Monitor1 Select | Set Monitor1 | | 0 ~ 3 | 0 |
| P2-14 | Monitor2 Select | Set Monitor2 | | 0 ~ 3 | 1 |
| <p>Set parameter to be displayed on the monitor. (0: Position, 1: Position Err, 2: Speed, 3: Torque)</p> | | | | | |
| | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|---|--------------|---------------|------|---------------|---------|
| P2-11 | Monitor1 ABS | Monitor1 Mode | | 0,1 | 0 |
| P2-15 | Monitor2 ABS | Monitor2 Mode | | 0,1 | 0 |
| <p>0: Displays type of symbols 1: Displays absolute values regardless of the type of symbols.</p> | | | | | |
| | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|--|----------------|-------------------|----------|---------------|---------|
| P2-12 | Monitor1 Scale | Monitor1 multiple | Multiple | 1.00 ~ 20.00 | 1.00 |
| P2-16 | Monitor2 Scale | Monitor2 multiple | Multiple | 1.00 ~ 20.00 | 1.00 |
| <p>This function, in case viewing is difficult because the analog output value is small, enables viewing by multiplying the parameter by appropriate multiples. For example, if 3 is input, the size of the parameter is enlarged by 3 times.</p> <p>Basic magnification: Position (10000.0/4[V]), Speed (maximum speed /4[V]) & Torque (3 x rated torque /4[V])</p> | | | | | |
| | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|---|-----------------|-----------------|------|----------------|---------|
| P2-13 | Monitor1 offset | Monitor1 offset | | -100.0 ~ 100.0 | 0.0 |
| P2-17 | Monitor2 offset | Monitor2 offset | | -100.0 ~ 100.0 | 0.0 |
| <p>This function enables output by applying appropriate offset to the analog output value. This is to allow adjustment of the value displayed on 0[V] potential, by applying offset to the monitor display. Unit is [%] and maximum value is 100[%]. Assuming maximum speed is 5000[rpm] and if offset 20 is input to display speed, 1000[rpm], 20[%] of 5000, is displayed on 0[V]</p> | | | | | |
| | | | | | |

5. Parameter Setting

| Menu | Menu title | Description | Unit | Display range | Default |
|-------|------------------|----------------------|------|---------------|---------|
| P2-18 | Resonant FRQ[Hz] | Resonant Frequency | Hz | 0 ~ 1000 | 300 |
| P2-19 | Resonant BW[Hz] | Frequency Band Width | Hz | 0 ~ 1000 | 100 |

Input the band width of resonant frequency and resonant frequency band in [Hz].

The graph illustrates the relationship between torque output and frequency. The vertical axis is labeled "Torque output" with values 1 and 0.707. The horizontal axis is labeled "Torque output frequency". A curve starts at (0, 1), reaches a minimum of 0.707 at a frequency labeled "Resonant frequency", and returns to 1 at a higher frequency. A double-headed arrow below the curve indicates the "Resonant freq. band width".

Use resonant frequency greater than $\frac{[[SC\ LOOP\ Gain(P2-02)]]}{6}$ [Hz]

| Menu | Menu title | Description | Unit | Display range | Default |
|---|-----------------|-------------------------|----------|---------------|---------|
| P2-20 | De-Resonant ENB | Resonant Removal Enable | | 0,1 | 0 |
| 0: Resonance removal operation stop 1: Resonance removal operating | | | | | |
| Menu | Menu title | Description | Unit | Display range | Default |
| P2-21 | Inertia Ratio | Inertia Ratio | Multiple | 1.0 ~ 500.0 | 1.0 |
| The system inertia is the sum of motor inertia and load inertia. This item sets the ratio of system inertia to motor inertia in terms of [times]. | | | | | |
| Inertia Ratio = $\frac{\text{System inertia (Motor inertia+load inertia)}}{\text{Motor inertia}}$ | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|---|----------------|---------------|------|---------------|---------|
| P2-22 | Autotune Range | Setting Range | | 0 ~ 9 | 0 |
| Prior to using the automatic setting function, input approximate ratio of system inertia to motor | | | | | |
| Inertia = $\frac{\text{System inertia (Motor inertia + load inertia)}}{\text{Motor inertia}}$ (to define the range) | | | | | |
| If the ratio of system inertia to motor inertia is unknown, input "0". | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|---|-------------------|--------------------|-------------|----------------------|----------------|
| P2-23 | Autotune ON/OFF | Autotune ON/OFF | | ON/OFF | OFF |
| ON: Auto set function is activated and the results are automatically stored in [SC LOOP Gain (P2-02)], [Inertia Ratio (P2-21)]. | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|--|-------------------|------------------------|-------------|----------------------|----------------|
| *P2-24 | Parameter Init | Restore default values | | Curr/dFLT | curr |
| When servo is used, parameters are set in various values. To restore parameters to servo's default value (basic set value) during operation, press Prog key. When "Parameter dFlt" is displayed on the screen, press Enter key. All parameters except the motor parameters ([P1-01] - [P1-09]) are restored to their default values. | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|---|-------------------|-----------------------|-------------|----------------------|----------------|
| *P2-25 | Powerfail Mode | Powerfail Mode Select | | 0,1 | By capacity |
| 0: Maintain ALARM starts until Reset : FDA6001C~04C 1: Reset automatic alarm when power supply recover alarm happens. : FDA6005C~150CN | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|---|-------------------|--------------------|-------------|----------------------|----------------|
| P2-26 | DB Control | DB Control Select | | 0,1 | 1 |
| <p>Enables quick motor control during servo operation by turning off SVONEN terminal and forming DB control circuit while the gating motion is turned off when the motor stops. However, if the DB control status is continuously maintained while the motor remains stopped, it is not easy to achieve free-run of the motor in case the user so desires. This menu therefore helps the user to achieve free-run of the motor by turning off the SVONEN terminal to create DB control circuit when controlling the motor and by opening the DB control circuit when the motor comes to a stop.</p> <p>0: The DB control circuit is activated only during motor control by turning off the SVONEN terminal of the motor, and free-run is activated only below 100[rpm] after the motor stops.</p> <p>1: DB control always operates even when the motor servo is turned off.</p> | | | | | |

5. Parameter Setting

| Menu | Menu title | Description | Unit | Display range | Default |
|---|------------------|----------------|-----------------|---------------|--------------|
| P2-27 | Display Select | Display Select | | 1~11 | 1 |
| Depending on the set value of [Display Select (P2-27)], the following initial menus can be displayed. | | | | | |
| VALUE | Initial Menu | VALUE | Initial Menu | VALUE | Initial Menu |
| 1 | CMD Position | 5 | Limit Speed | 9 | Program Ver. |
| 2 | Current Position | 6 | Torque Limit(%) | 10 | I/O Status |
| 3 | Position Error | 7 | Load Rate(%) | 11 | P5 - 01 |
| 4 | Motor Speed | 8 | Max.Load Rate | | |

If set value of [Display Select(P2-27)] is eleven, when power is ON, initial screen is displayed in parameter position CMD0[P5-01]. If we change the set value, position transportation quantity is also changed.
(It must be appointed in Position CMD0 by input contact COMSEL0-4)

| Menu | Menu title | Description | Unit | Display range | Default |
|--|------------------|------------------|-------|---------------|---------|
| P2-28 | Zero SPD VIB RJT | Zero SPD VIB RJT | [rpm] | 0.0 ~ 100.0 | ON |
| If the motor vibrates at low speed, including zero speed, input the speed range desired to remove vibration from in terms of [rpm]. | | | | | |
| In this case, increase the set value on a gradual basis until vibration is reduced. However, when 0.0 is set, the zero speed vibration rejection function will not operate. | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|---|----------------|----------------|------|---------------|---------|
| P2-29 | Conform ON/OFF | Conform ON/OFF | | ON/OFF | ON |
| This menu controls confirmation work when parameters are input. If ON is selected, the servo reconfirms parameter change through the message "OK?" prior to changing parameters. If OFF is selected, the servo changes parameters without going through confirmation process. | | | | | |
| This menu is supported only on digital loaders. Parameters are changed without confirmation on mount loaders. | | | | | |

5.4 Speed control parameter (Speed Mode : P3--)

| Menu | Menu title | Description | Unit | Display range | Default |
|-------|-----------------|--------------|-------|---------------|---------|
| P3-01 | Group SPD0[rpm] | Group0 speed | [rpm] | 0.0 ~ 9999.9 | 100 |
| P3-02 | Group SPD1[rpm] | Group1 speed | [rpm] | 0.0 ~ 9999.9 | 500 |
| P3-03 | Group SPD2[rpm] | Group2 speed | [rpm] | 0.0 ~ 9999.9 | 1000 |
| P3-04 | Group SPD3[rpm] | Group3 speed | [rpm] | 0.0 ~ 9999.9 | 1500 |

Input Limit Speed of position CMD[0-07] to [Group SPD0] in [rpm]. In the same way, input limit speed of position CMD[08-15], position CMD[16-23], Position CMD[24-30] to [Group SPD1], [group SPD2], [Group SPD3] respectively.

| Menu | Menu title | Description | Unit | Display range | Default |
|-------|-----------------|-------------------------|------|---------------|---------|
| P3-05 | Group ACC0[ms] | Group0 acceleration | [ms] | 0 ~ 10000 | 10 |
| P3-06 | Group ACC1[ms] | Group1 acceleration | [ms] | 0 ~ 10000 | 20 |
| P3-07 | Group ACC2[ms] | Group2 acceleration | [ms] | 0 ~ 10000 | 30 |
| P3-08 | Group ACC3[ms] | Group3 acceleration | [ms] | 0 ~ 10000 | 40 |
| P3-09 | Origin ACC [ms] | Origin/Jog acceleration | [ms] | 0 ~ 10000 | 10 |
| P3-10 | Group DEC0[ms] | Group0 deceleration | [ms] | 0 ~ 10000 | 10 |
| P3-11 | Group DEC1[ms] | Group1 deceleration | [ms] | 0 ~ 10000 | 20 |
| P3-12 | Group DEC2[ms] | Group2 deceleration | [ms] | 0 ~ 10000 | 30 |
| P3-13 | Group DEC3[ms] | Group3 deceleration | [ms] | 0 ~ 10000 | 40 |
| P3-14 | Origin DEC [ms] | Origin/Jog deceleration | [ms] | 0 ~ 10000 | 10 |

[Group Acc] inputs acceleration time in terms of [ms] from the stopped status up to the rated speed. If 10 is loaded, speed is accelerated for 10 [ms] up to the rated speed from the stopped status. To increase the acceleration time to the maximum, input 0.


[Group DEC] inputs deceleration time in terms of [ms] from the rated speed to the stopped status. If 10 is loaded, speed is decelerated for 10 [ms] from the rated speed to the stopped status. To increase the deceleration time to the maximum, input 0.

Input deceleration/acceleration time of position CMD[0~07] to [Group ACC0],[Group DEC0]

Input deceleration/acceleration time of position CMD[08~15] to [Group ACC1],[Group DEC1]

Input deceleration/acceleration time of position CMD[16~23] to [Group ACC2],[Group DEC2]

Input deceleration/acceleration time of position CMD[24~31] to [Group ACC3],[Group DEC3]



5. Parameter Setting

| Menu | Menu title | Description | Unit | Display range | Default |
|---|------------|------------------------|------|---------------|---------|
| *P3-15 | FDELAY | Speed trajectory delay | ms | 0.0 ~ 100.0 | 0.0 |
| <p>If vibration and noise happens to the motor, after the motor speed detection value passes through the primary delay filter, input the delay time constant in [msec]. In case noise occurs on the motor shaft during feeding due to vibration, adjust the delay time constant value to reduce noise level. If the value is adjusted too much at a time, problem may occur on speed control. Gradually increase the [FDELAY (P3-15)] set value from 0.</p> <p>Recommended maximum set value = [SC_I_TC (P2-03) set value]</p> <p>(Example) If P2-03 is 20 [msec], the maximum FDELAY set value is 20, and the speed feedback delay time is 20 [msec].</p> | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default | | | | | | |
|---|-------------|-------------|-------|---------------|---------|-------------|-------------|---|-----|----|-----|
| *P3-16 | 10 V Speed | 10 V Speed | [rpm] | 0.0 ~ 9999.0 | 0 | | | | | | |
| <p>In case of override speed input : Input the rotation speed in [rpm] when the analog speed command 10[V] is loaded.</p> <table border="1"> <caption>Data points from the graph</caption> <thead> <tr> <th>Voltage [V]</th> <th>Speed [rpm]</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>100</td> </tr> <tr> <td>10</td> <td>200</td> </tr> </tbody> </table> | | | | | | Voltage [V] | Speed [rpm] | 0 | 100 | 10 | 200 |
| Voltage [V] | Speed [rpm] | | | | | | | | | | |
| 0 | 100 | | | | | | | | | | |
| 10 | 200 | | | | | | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|----------------------|----------------------|----------------------|------|---------------|---------|
| P3-17 | Zero Clamp Mode | Zero Clamp Mode | | 0 ~ 2 | 0 |
| 0 : Zero Clamp Mode0 | 1 : Zero Clamp Mode1 | 2 : Zero Clamp Mode2 | | | |
| | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|-----------------------------------|----------------|-------------------|------|---------------|---------|
| P3-18 | Clamp VOLT[mV] | Set Clamp Voltage | [mV] | -1000 ~ 1000 | 0 |
| Input Zero Clamp voltage in [mV]. | | | | | |

5.5 Position control parameter (Position Mode: P4--)

| Menu | Menu title | Description | Unit | Display range | Default |
|---|----------------|------------------|------|---------------|---------|
| P4-01 | Feedforward[%] | Feedforward Gain | % | 0 ~ 100 | 0 |
| Input the Feedforward rate of the position command speed in [%]. The delay element of the position controller can be reduced if the value of this item is increased. However, if the value is increased excessively, overshoot may occur on the position system, or performance of the position controller is deteriorated. Select appropriate value. If this value is 0, the position controller becomes a simple position proportional controller. Refer to the following MAX [Feedforward] value for each K=[SC LOOP Gain]/[PC P Gain] value. | | | | | |
| | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|--|-------------|-------------------|------|---------------|---------|
| P4-02 | In Position | In position range | User | 0.001 ~ 99999 | 0.1 |
| Input the error range of the position where (INPOS) contact is turned ON in the unit of User. In other words, if the difference between the position pulse and command pulse is within the range set at [In Position (P4-02)], (INPOS) is turned ON. | | | | | |

| Menu | Menu title | Description | Unit | Display range | Default |
|--|------------------|--------------------|------|-------------------|---------|
| P4-03 | FLLW ERR [PULSE] | Follow pulse error | User | -9999.9 ~ 99999.9 | 90000 |
| Set the range of the transient position error detection in [User] When MPG mode, In normal condition, the pulse error is $\frac{1-0.01 \times [\text{Feedforward (P4-01)}]}{[\text{PC P Gain (P2-02)}]} \times (\text{MPG input pulse freq[Hz]}) \times \begin{cases} \text{Move Mechanical} & \text{Move motor*4*Encoder pls} \\ \end{cases}$ In case ([Pulse Logic (P4-04)] is 0 or 3, set value greater than x4) value. Set the greater value than this. | | | | | |
| | | | | | |

5. Parameter Setting

| Menu | Menu title | Description | Unit | Display range | Default |
|--------|---------------|-----------------------|------|----------------------|---------|
| *P4-04 | Pulse Logic | Command Pulse Type | | 0 ~ 5 | 0 |
| | | Type of command pulse | | Remark | |
| | [Pulse Logic] | CCW | CW | | |
| | 0 | PF PR | | A phase +B phase | |
| | 1 | PF PR | | CCW pulse + CW pulse | |
| | 2 | PF PR | | Direction + pulse | |
| | 3 | PF PR | | A phase +B phase | |
| | 4 | PF PR | | CCW pulse + CW pulse | |
| | 5 | PF PR | | Direction + pulse | |

| Menu | Menu title | Description | Unit | Display range | Default |
|-------|---------------|----------------------|------|---------------|---------|
| P4-05 | FF FLT TC[ms] | FF FLT Time Constant | ms | 0 ~ 10000 | 0 |

Input the primary filter time constant of the position command speed Feedforward in [msec]. The loaded position command is differentiated and passes through the primary filter before it is used as the Feedforward input. The time constant of this filter can be adjusted. Increase this value in applications where the position command is rapidly changed, and decrease this value in applications where the position command is slowly changed. Input 0 in case it is not needed to use this filter.

| Menu | Menu title | Description | Unit | Display range | Default |
|-------|---------------|---------------------------------------|------|---------------|---------|
| P4-06 | S-Type TC[ms] | Position command filter time constant | ms | 0 ~ 10000 | 0 |

Input the filter time constant of the position command input in [ms]. The output which passes through the primary filter is used as the position command for the loaded position command. Set the time constant of this filter. Enter 0 in case it is not needed to use this filter.

5.6 Position Command Parameter(POS Command Mode : P5--)

| Menu | Menu title | Description | unit | Range | Default |
|-------------|-------------------|---------------------|-------------|------------------|----------------|
| P5-01 | Position CMD0 | position command 0 | USER | -99999.9~99999.9 | 10 |
| P5-02 | Position CMD1 | position command 1 | USER | -99999.9~99999.9 | 20 |
| P5-03 | Position CMD2 | position command 2 | USER | -99999.9~99999.9 | 30 |
| P5-04 | Position CMD3 | position command 3 | USER | -99999.9~99999.9 | 40 |
| P5-05 | Position CMD4 | position command 4 | USER | -99999.9~99999.9 | 50 |
| P5-06 | Position CMD5 | position command 5 | USER | -99999.9~99999.9 | 60 |
| P5-07 | Position CMD6 | position command 6 | USER | -99999.9~99999.9 | 70 |
| P5-08 | Position CMD7 | position command 7 | USER | -99999.9~99999.9 | 80 |
| P5-09 | Position CMD8 | position command 8 | USER | -99999.9~99999.9 | 90 |
| P5-10 | Position CMD9 | position command 9 | USER | -99999.9~99999.9 | 100 |
| P5-11 | Position CMD10 | position command 10 | USER | -99999.9~99999.9 | 110 |
| P5-12 | Position CMD11 | position command 11 | USER | -99999.9~99999.9 | 120 |
| P5-13 | Position CMD12 | position command 12 | USER | -99999.9~99999.9 | 130 |
| P5-14 | Position CMD13 | position command 13 | USER | -99999.9~99999.9 | 140 |
| P5-15 | Position CMD14 | position command 14 | USER | -99999.9~99999.9 | 150 |
| P5-16 | Position CMD15 | position command 15 | USER | -99999.9~99999.9 | 160 |
| P5-17 | Position CMD16 | position command 16 | USER | -99999.9~99999.9 | 170 |
| P5-18 | Position CMD17 | position command 17 | USER | -99999.9~99999.9 | 180 |
| P5-19 | Position CMD18 | position command 18 | USER | -99999.9~99999.9 | 190 |
| P5-20 | Position CMD19 | position command 19 | USER | -99999.9~99999.9 | 200 |
| P5-21 | Position CMD20 | position command 20 | USER | -99999.9~99999.9 | 210 |
| P5-22 | Position CMD21 | position command 21 | USER | -99999.9~99999.9 | 220 |
| P5-23 | Position CMD22 | position command 22 | USER | -99999.9~99999.9 | 230 |
| P5-24 | Position CMD23 | position command 23 | USER | -99999.9~99999.9 | 240 |
| P5-25 | Position CMD24 | position command 24 | USER | -99999.9~99999.9 | 250 |
| P5-26 | Position CMD25 | position command 25 | USER | -99999.9~99999.9 | 260 |
| P5-27 | Position CMD26 | position command 26 | USER | -99999.9~99999.9 | 270 |
| P5-28 | Position CMD27 | position command 27 | USER | -99999.9~99999.9 | 280 |
| P5-29 | Position CMD28 | position command 28 | USER | -99999.9~99999.9 | 290 |
| P5-30 | Position CMD29 | position command 29 | USER | -99999.9~99999.9 | 300 |
| P5-31 | Position CMD30 | position command 30 | USER | -99999.9~99999.9 | 310 |
| P5-32 | Position CMD31 | position command 31 | USER | -99999.9~99999.9 | 320 |

If push the ENTER-Key in Digital Loader(P5-01 ~ P5-32). We can enter the loader Jog Mode In Position command subordinate mode

5. Parameter Setting

[Loader Jog Mode]

The jog Mode comprises sub-menu of position command mode.

The jog mode operates even when status of non-contact, only possible in Digital Loader.

Input position command by User's unit.

Digital loader: "ENTER-Key"

| Menu | Menu title | Description | Unit | Range | Default |
|--------------------------|------------|--------------|------|----------------|---------|
| | JOG State0 | Loader Jog 0 | | -9999.9~9999.9 | |
| Display current position | | | | | |

If >(right) key is pressed, motor runs CW with Jog Speed 0[P6-05].

If <(left) key is a pressed, motor run CCW with Jog Speed 0.

Digital Loader: "DOWN-Key"

| Menu | Menu title | Description | Unit | Range | Default |
|---------------------------|------------|--------------|------|----------------|---------|
| | JOG State1 | Loader Jog 1 | | -9999.9~9999.9 | |
| Display current position. | | | | | |

If >(right) key is pressed, motor runs CW with Jog Speed 1[P6-06].

If <(left) key is pressed, motor runs CCW with Jog Speed 1.

Digital Loader: "DOWN-Key"

| Menu | Menu title | Description | Unit | Range | Default |
|--------------------------|-------------|----------------|------|----------------|---------|
| | IJOG State0 | Loader I Jog 0 | | -9999.9~9999.9 | |
| Display current position | | | | | |

If >(right) key is pressed, motor runs CW like the position at INC Jog Value0 [P6-07],

If <(left) key is a pressed, motor run CCW like the position at INC Jog Value0.

Digital Loader: "DOWN-Key"

| Menu | Menu title | Description | Unit | Range | Default |
|--------------------------|-------------|----------------|------|----------------|---------|
| | IJOG State1 | Loader I Jog 1 | | -9999.9~9999.9 | |
| Display current position | | | | | |

If >(right) key is pressed, motor runs CW like the position at INC Jog Value1 [P6-08],

If <(left) key is a pressed, motor run CCW like the position at INC Jog Value1.

Digital Loader "ENTER-Key": Save Current Position Data at Position CMD

Digital Loader "PROG-Key": Not save Current Position Data at Position CMD

5.7 Jog/Original Mode Parameter (Jog/Origin Mode: P6--)

| Menu | Menu title | Description | Unit | Range | Default |
|--|------------------|--------------------------|------|------------|---------|
| P6-01 | Origin SPD0[rpm] | Origin operation speed 0 | rpm | 0.0~9999.9 | 50 |
| P6-02 | Origin SPD1[rpm] | Origin operation speed 1 | rpm | 0.0~9999.9 | 10 |
| Move [Origin SPD0] to the ultimate contact point position when operation in origin and move[Orgin SPD1] to the z-pulse point position. | | | | | |

| Menu | Menu title | Description | Unit | Range | Default |
|--|------------------|----------------------|------|-----------|---------|
| P6-03 | Origin Torque[%] | Damper origin torque | % | 0.0~300.0 | 50 |
| [Origin Torque] is used to discern the collision machinery part with Damper when operation in Damper Origin. If this value is 100[%], torque is rated, discern that it collided the damper, start rotation in opposite direction | | | | | |

| Menu | Menu name | Description | Unit | Range | Default |
|---------------------------------------|---------------|-----------------------------|------|----------------|---------|
| P6-04 | Origin Offset | Coordinates value of origin | User | -9999.9~9999.9 | 0 |
| Input the coordinates value of users. | | | | | |

| Menu | Menu title | Description | Unit | Range | Default |
|--|-----------------|-----------------------|------|------------|---------|
| P6-05 | Jog Speed0[rpm] | Jog operation speed 0 | rpm | 0.0~9999.9 | 100 |
| P6-06 | Jog Speed0[rpm] | Jog operation speed 0 | rpm | 0.0~9999.9 | 200 |
| Use [Jog Speed 0] with move speed value, when operating in Jog Mode with contact point Can use Jog speed of two steps when operating in Digital Loader | | | | | |

| Menu | Menu title | Description | Unit | Range | Default |
|--|----------------|-----------------|------|------------|---------|
| P6-07 | INC Jog Value0 | INC Jog moving0 | User | 0.0~9999.9 | 50 |
| P6-08 | INC Jog Value0 | INC Jog moving1 | User | 0.0~9999.9 | 100 |
| When operating in incremental jog, can set the moving quantity about one command with two steps. Input moving quantity with user's coordinates value moving speed cannot be set by user operation in jog is only possible Digital Loader | | | | | |

5. Parameter Setting

5.8 Mechanical Parameter (Mechanical Mode : P7--)

| Menu | Menu title | Description | Unit | Range | Default |
|--------|-----------------|-------------|------|---------|---------|
| *P7-01 | Move Motor | | USER | 1~10000 | 1 |
| *P7-02 | Move Mechanical | | USER | 1~10000 | 100 |

Moving motor and Move Mechanical set the rate of moving quantity of user's coordinates and the encoder pulse number equivalent this.

Ex) 1) If we hope to use the coordinates of unit in [mm] about the machine which moves 10.0mm per rotation, only set Move Motor='1' and Move Machines='10'

2) If we hope to use the coordinates of unit in [degree] about the machine which moves 360.0 degree per fifty rotations, only set Move Motor='50' and Move Machines='360'

| Menu | Menu title | Description | Unit | Range | Default |
|--------|---------------|-----------------------|------|-------|---------|
| *P7-03 | Move Polarity | Direction of movement | | 0~1 | 1 |

0: User's coordinates is increased, when motor rotates opposite direction(CW direction)
 Ex) When use the input contact point CCWJOG : Motor rotates CW direction.
 When use the input contact point CWJOG : Motor rotates CCW direction.
 1: User's coordinates is increase, when motor rotates right direction(CCW direction)

| Menu | Menu title | Description | Unit | Range | Default |
|--------|--------------|------------------------------|------|---------|---------|
| *P7-04 | Turret Cycle | Position on mechanical cycle | User | 0~10000 | 0 |

When move 360.0 degree structures coordinates of machine, approach the same point again, as in the case of irrelevant to rotation direction, if wish to move from the current position 359.0 degree to 0.0, it needs movement of -359.0 degree. But if only move current position 359.0 by 1.0 because 0.0 equal to 360.0, approach to the wanted points.
 As in the case of this, if Turret Cycle value is set to 360.0. It is controller by automatically moving near direction when operation (short distance discrimination function)
 (Caution!) Short distance discrimination function must only use in Turret Operation.
 When exists pressed pipe or wire in lead side, using Turret Cycle function, don't use wiring can get intertwined.
 If Turret Cycle value is set to 0.0, this function doesn't be used.

| Menu | Menu title | Description | Unit | Range | Default |
|--------|----------------|----------------------------|------|---------|---------|
| *P7-05 | MPG Move[REV]] | Rotation quantity of motor | User | 0~10000 | 1 |

Set the rotation quantity about input command pulse or MPG pulse

| Menu | Menu title | Description | Unit | Range | Default |
|---|----------------|-------------|------|----------|---------|
| *P7-06 | MPG Pulse[REV] | | User | 0~100000 | 100 |
| Set command pulse or MPG pulse input quantity. Ex) If set to P7-05=1, P7-06=100, when MPG pulse is putted 100 pulse motor rotates one revolution Namely, pulse number/one revolution= P7-06/P7-05= 100 pulse / 1 rotation | | | | | |

| Menu | Menu title | Description | Unit | Range | Default |
|--|----------------|--|------|--------|---------|
| *P7-07 | Angle Division | Angle division stop when Jog operation | User | 0~1000 | 0 |
| When using turret operation mode, as in the case of stopping in JOG operation, Set the ordinary rate of the angle that is stopped. Ex) If set value=30 When operating in JOG Mode, as in the case of inputting the stop command in optional angle only stop the multiples of 30 degree which is set (Danger !) RUN_MODE[P8-01]: Only applied in zero turret operation Digital Loader As in the case of IJOG transportation by Digital Loader and stop by input contact point STOP. Angle-division-stop doesn't operate | | | | | |

5. Parameter Setting

5.9 Operational Mode Parameter (Operation Mode : P8--)

| Menu | Menu title | Description | Unit | Range | Default |
|--------|------------|----------------|------|-------|---------|
| *P8-01 | RUN_MODE | Operation Mode | | 0~7 | 1 |

Set the operation type (3.3.4 reference the operation timing diagram)

0 : Absolute position operation (Turret operation)
Can choose the absolute position in COMSEL0-4, if the position come to by the input of START signal, position completed signal is displayed by OP0-4.
Also, as in the case of using with angle operation like Turret of construction machines, if Turret Cycle(P7-04) is set to 360, short distance discrimination function is operated. If it always hopes to stop in the multiple of fixed angle, during the operation by input contact point JOG terminal, use Angle Division(P7-07)

1 : Relative position STEP Manual operation (Roll Feeder STEP Manual operation)
Can choose the relative position in COMSEL0-4, display the position completed signal by INPOS position

2 : Relative position AUTO Manual operation (Roll Feeder AUTO Manual operation)
Can choose the relative position in COMSEL0-4, if START signal is putted on time, it's position transports stop time during continuous transportation is set by STOP_TIME(P8-02), if approached the position, display the position completed signal by INPOS position

3 : Absolute sequence STEP Manual operation, whenever put the START Signal the sequenced set value 4Point(Position CMD 0,8,16,24) about absolute position, position is transported, if approaches the position.

4 : Absolute position sequence STEP Auto operation
If put a START signal sequenced set value 4Point(Position CMD 0,8,16,24) about absolute position, it's position is transported stop time during continuous transportation is set by STOP_TIME(P8-02). If approach the position, display the position complete signal by INPOS.

5 : Relative Position PROCESS Operation
If START signal is putted on time, transport in the CCW direction. At this time, speed is Origin Spd0(P6-01).
After that, detect Dog signal and transport to selected relative position in COMSEL0-4.
* caution : can't execute seeking the origin point in process operation.

Danger! After RUN_MODE changes, it is necessary that we use after origin operation.
It may cause an accident.

| Menu | Menu title | Description | Unit | Range | Default |
|---|------------|----------------|------|-------|---------|
| *P8-01 | RUN_MODE | Operation Mode | | 0~7 | 1 |
| Set the operation type (3.3.4 reference the operation timing diagram) | | | | | |
| 6 : Relative Position PROCESS Operation | | | | | |

If START signal is putted on time, transport in the CW direction. At this time, speed is Origin Spd0(P6-01).

After that, detect Dog signal and transport to selected relative position in COMSEL0-4.

- * caution : can't execute seeking the origin point in process operation.
- * 5,6 PROCESS Operation is the same except initial direction.

7 : Absolute Position RETURN Operation

If START signal is putted on time, return to selected absolute position in COMSEL0-4.

If you start input once more, system is not transported.

Danger!) After RUN_MODE changes, it is necessary that we use after origin operation.

It may cause an accident.

| Menu | Menu title | Description | Unit | Range | Default |
|---|------------|--------------------------------|------|---------|---------|
| P8-02 | STOP_TIME | Continuous operation stop time | ms | 0~10000 | 10 |
| When operation in relative position STEP Auto operation/Absolute position sequence STEP Auto operation MODE set stop time of each step the unit in [ms] | | | | | |

| Menu | Menu title | Description | Unit | Range | Default | | | | | | | | | | | | | | | | | | | | | | | |
|--|----------------------|-----------------------|---------------------|--------------------|-----------------|---------------|--|--|--|----------------------|--------------------|---------------------|--------------------|---|----------|---------|---------|---------|---|--------|-------|---------|---------|---|----------|---------|--------|-------|
| *P8-03 | LIM_SEL | Limit<->Jog<->Lim,Jog | | 0~2 | 0 | | | | | | | | | | | | | | | | | | | | | | | |
| Can choose the function of input contact point switch CCWLimit, CWLimit 0: Operate the function of CCWLimit, CWLimit 1: Operate the function of CCWJog, CWJog 2: Operate the function of CCWLimit, CWLimit, CCWJog & CWJog | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th rowspan="2">Parameter Value</th> <th colspan="4">Input Contact</th> </tr> <tr> <th>CCWLimit/CCWJOG (40)</th> <th>CWLimit/CWJOG (14)</th> <th>COMSEL2/CCWJOG (17)</th> <th>COMSEL3/CWJOG (42)</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>CCWLimit</td> <td>CWLimit</td> <td>COMSEL2</td> <td>COMSEL3</td> </tr> <tr> <td>1</td> <td>CCWJOG</td> <td>CWJOG</td> <td>COMSEL2</td> <td>COMSEL3</td> </tr> <tr> <td>2</td> <td>CCWLimit</td> <td>CWLimit</td> <td>CCWJOG</td> <td>CWJOG</td> </tr> </tbody> </table> | | | | | Parameter Value | Input Contact | | | | CCWLimit/CCWJOG (40) | CWLimit/CWJOG (14) | COMSEL2/CCWJOG (17) | COMSEL3/CWJOG (42) | 0 | CCWLimit | CWLimit | COMSEL2 | COMSEL3 | 1 | CCWJOG | CWJOG | COMSEL2 | COMSEL3 | 2 | CCWLimit | CWLimit | CCWJOG | CWJOG |
| Parameter Value | Input Contact | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | CCWLimit/CCWJOG (40) | CWLimit/CWJOG (14) | COMSEL2/CCWJOG (17) | COMSEL3/CWJOG (42) | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | CCWLimit | CWLimit | COMSEL2 | COMSEL3 | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | CCWJOG | CWJOG | COMSEL2 | COMSEL3 | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | CCWLimit | CWLimit | CCWJOG | CWJOG | | | | | | | | | | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

5. Parameter Setting

| Menu | Menu title | Description | Unit | Range | Default |
|--|-----------------|-------------------|------|-------|---------|
| *P8-04 | Soft Lim Enable | Soft Limit Select | | 0~1 | 0 |
| Prevent motor from over travel by P8-05(CCWLIM) & P8-06(CWLIM) values. | | | | | |
| 0: Cannot use Soft Limit function 1: Can use Soft Limit function | | | | | |

| Menu | Menu title | Description | Unit | Range | Default |
|--------------------------------|-------------|----------------------|------|----------------|---------|
| *P8-05 | Soft CCWLIM | CCWLIM Position Data | User | -100000~100000 | 99999.0 |
| Input CCW Limit position data. | | | | | |

| Menu | Menu title | Description | Unit | Range | Default |
|-------------------------------|------------|---------------------|------|----------------|----------|
| *P8-06 | Soft CWLIM | CWLIM Position Data | User | -100000~100000 | -99999.0 |
| Input CW Limit position data. | | | | | |

| Menu | Menu title | Description | Unit | Range | Default |
|---|------------|-------------------------|------|-------|---------|
| *P8-07 | Dog Select | Origin Return Operation | | 0~1 | 0 |
| Origin Dog contact is used for origin return function(Only P8-01= "0") | | | | | |
| 0: Cannot operate Origin return function 1: Can operate Origin return function | | | | | |

| Menu | Menu title | Description | Unit | Range | Default |
|--|------------|----------------------------|------|-------|---------|
| *P8-08 | AUTO_ORG | Automatic Origin operation | | 0~1 | 0 |
| If first makes SVON after putting the power source, can automatically operate Origin function by ORG_RULE(P8-09) | | | | | |
| 0: Cannot operate automatically Origin function 1: Can operate automatically Origin function | | | | | |

| Menu | Menu title | Description | Unit | Range | Default | | | | | | | | | |
|---|------------------------------|---------------------------------------|------|-------|---------|---------------|----------------|-------------|------------|----------------------|---|-------------|------------------------------|---------------------------------------|
| *P8-09 | ORG_RULE | Operation method of origin | | 0~24 | 2 | | | | | | | | | |
| Can set the method of seeking the origin point 0: Don't seek the origin point.(when the power source is on, it's position is the origin, as in the case of this, ORGOUT output is maintained state) 1,2 : Seek the origin point by using the CWLimit 3,4 : Seek the origin point by using the CCWLimit 5,6 : Seek the origin point by using the CWLimit Switch and origin DOG switch 7,8 : Seek the origin point by using the CCWLimit Switch and origin DOG switch 9,10 : Progress in CW->CCW direction, seek the origin point by using origin DOG switch 11,12 : Progress in CCW->CW direction, seek the origin point by using origin DOG switch 13,14 : Seek the origin point by using the CW Damper 15,16 : Seek the origin point by using the CCW Damper 17,18 : Progress in CW->CCW direction, seek the origin point(Z phase position) 19,20 : Progress in CCW->CW direction, seek the origin point (Z phase position) 21,22 : Progress in CW->CCW direction, seek the origin point (origin DOG signal position) 23,24 : Progress in CCW->CW direction, seek the origin point (origin DOG signal position) | | | | | | | | | | | | | | |
| Right direction in situation of servo motor is rotation direction when operation phase rotation U->V->W in sequence as in the case of our company motor it is CCW direction When use the CCW with switch establish the tail of the right direction rotation (CW is opposite direction) by the operation method in, ultimate origin point change. | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Operation way</th><th>Final Position</th><th>Final Value</th></tr> </thead> <tbody> <tr> <td>Odd number</td><td>Origin OFFSET(P6-04)</td><td>0</td></tr> <tr> <td>Even number</td><td>Final z phase pulse position</td><td>Origin Offset(P6-04) Setting value</td></tr> </tbody> </table> | | | | | | Operation way | Final Position | Final Value | Odd number | Origin OFFSET(P6-04) | 0 | Even number | Final z phase pulse position | Origin Offset(P6-04) Setting value |
| Operation way | Final Position | Final Value | | | | | | | | | | | | |
| Odd number | Origin OFFSET(P6-04) | 0 | | | | | | | | | | | | |
| Even number | Final z phase pulse position | Origin Offset(P6-04) Setting value | | | | | | | | | | | | |

(reference !) A detailed contact reference that follows chapter six origin point operation method.

(Caution !) Origin point operation method of absolute value encoder reference the menu P8-11[ABS_ORG_SET]

| Menu | Menu title | Description | Unit | Range | Default |
|--|------------|-------------|------|-------|---------|
| *P8-10 | MPG_SEL | Select MPG | | 0~1 | 0 |
| Can choose presence of MPG function 0: Can't use MPG function 1: Can use MPG function COMSEL4/MPGEN contact point='1' of input As, in the case of this, position command be able to use to position CMD0-15 using input contact point COMSEL0-3 | | | | | |

5. Parameter Setting

| Menu | Menu title | Description | Unit | Range | Default |
|--|-------------|--------------------------------------|------|-------|---------|
| *P8-11 | ABS_ORG_SET | Set origin point of Absolute encoder | | 0~1 | 0 |
| This is the menu of operating the origin point of absolute type encoder. | | | | | |
| Ex) Consider to motor for absolute type encoder, after move motor to the position equivalent to origin point, if set the P8-07[ABS_ORG_SET]=1, over changing 1->0 after 1-2 seconds, current position is considered as an origin point | | | | | |

| Menu | Menu title | Description | Unit | Range | Default |
|--|------------------|-----------------------------------|------|-------|---------|
| *P8-12 | IN POSITION TYPE | INPOS Complete Signal Output Type | | 0~1 | 1 |
| You can select INPOS Complete Signal Output Type | | | | | |
| 0 : When position decision ,Selected Position CMD0~31 Output via OP0 ~ OP4 | | | | | |
| 1 : When position decision , Output via INPOS | | | | | |

| Menu | Menu title | Description | Unit | Range | Default |
|---|-------------|-------------------------|------|---------|---------|
| *P8-13 | STOP SELECT | STOP Function selection | | 0, 1, 2 | 0 |
| This function is available to RETURN Operation (P8-01="7"). | | | | | |
| 0 : Stop at present position | | | | | |
| 1 : Stop at Start position | | | | | |
| 2 : Stop at Command position | | | | | |

| Menu | Menu title | Description | Unit | Range | Default |
|---------------------------------|------------|-------------------|------|----------------|---------|
| P8-14 | Ias Offset | Save Offset value | | -99.999~99.999 | |
| Save Ias_Offset Value to P8-14. | | | | | |

| Menu | Menu title | Description | Unit | Range | Default |
|---------------------------------|------------|-------------------|------|----------------|---------|
| P8-15 | Ics Offset | Save Offset value | | -99.999~99.999 | |
| Save Ics_Offset Value to P8-15. | | | | | |

| Menu | Menu title | Description | Unit | Range | Default |
|-----------------------|-------------------|---------------------------------|-------------|----------------|----------------|
| *P8-16 | Command ABS Data | Multi-Turn Data On CMD Position | | -100000~100000 | |
| Save Multi-Turn Data. | | | | | |

| Menu | Menu title | Description | Unit | Range | Default |
|-----------------------|-------------------|---------------------------------|-------------|----------------|----------------|
| *P8-17 | Current ABS Data | Multi-Turn Data On CUR Position | | -100000~100000 | |
| Save Multi-Turn Data. | | | | | |

| Menu | Menu title | Description | Unit | Range | Default |
|--|-------------------|--------------------|-------------|--------------|----------------|
| *P8-18 | ABS Counter 2 | Abs Encoder Data | | -99999~99999 | |
| Save compensated value of Multi-Turn Data overflow prior to RESET in Turret Cycle. (Abs Encoder Overflow reset compensated value) | | | | | |

| Menu | Menu title | Description | Unit | Range | Default |
|--|-------------------|--------------------|-------------|--------------|----------------|
| *P8-19 | ABS Counter 1 | Abs Encoder Data | | -99999~99999 | |
| Save position data of Multi-Turn 1024 unit prior to power off . (Abs Encoder the latest Multi-Turn portion → Display 8 portion of 8192 Turns) | | | | | |

| Menu | Menu title | Description | Unit | Range | Default |
|---|-------------------|--------------------|-------------|--------------|----------------|
| *P8-20 | ABS Counter 0 | Abs Encoder Data | | -99999~99999 | |
| Save the initial value of encoder in ABS Encoder origin initialization. | | | | | |

5. Parameter Setting

5.10 Description of servo status (Status Window: St--)

| Screen display | Description |
|----------------------------|--|
| CMD Position St-01 | Indicates current command position |
| Current Position St-02 | Indicates current position |
| Position Error St-03 | Indicates the difference between the current command position and current position |
| Motor Speed [rpm] St-04 | Indicates current motor speed in [rpm] |
| Limit Speed [rpm] St-05 | Indicates maximum command speed in [rpm] |
| Torque Limit [%] St-06 | Indicates current torque limit value in [%] |
| Load Rate [%] St-07 | Indicates load rate [%] based on torque |
| Max Load Rate [%] St-08 | Indicates maximum load rate [%] based on torque |
| Program Version St-09 | Indicates current program version |
| I/O CON. STATUS St-10 | Indicates contact I/O status |

5.10.1 Digital Loader

(1) Input signal display

The status of input contact recognized within the system is indicated with either "0" or "1". Therefore, if the status input from the external sources is different from the displayed information, it indicates problem on the input system. As each signal carries different meaning, explanation is provided through examples below.

(Example of display)

| | | | | | | | | | | | | |
|---------|---------|--------|-----|-------|--------|--------|-------|---------------------|---|---|---|---|
| VALUE : | 0 | 0 | 0 | 1 | 0 | 1 | 1 | 0 | 0 | 0 | 0 | 1 |
| NAME : | ALIMRST | ORGCOM | ORG | CWLIM | CCWLIM | SVONNE | START | COMSEL[4,3,2,1,0] | | | | |

1: Input signal operating

0: Input signal not operating

| Signal | Display | Description |
|---------------------|---------|--|
| COMSEL0 | 1 | Position command = set Position CMD[1] |
| COMSEL1 | 0 | |
| COMSEL2/ CCWJOG | 0 | |
| COMSEL3/ CWJOG | 0 | |
| COMSEL4/ MPGEN | 0 | |
| START | 1 | JOB start command operation |
| SVONEN | 1 | Servo motor start command operation |
| CCWLIM/ CCWJOG | 0 | CCW direction rotation not possible |
| CWLIM/ CWJOG | 1 | CW direction rotation possible |
| ORG-DOG/ ORG-RET | 0 | Situate outside Dog switch domain |
| ORGCOM | 0 | Origin Command disable |
| ALIMRST | 0 | Alarm reset function disable |

The above examples are based on the current status of each signal. System operates in reverse if signals are in opposite status

(2) Output signal display

As each signal carries different meaning, explanation is provided through examples below.

(Example of display)

| | | | | | | | | | |
|---------|-----|-----|-----|-----|-----------|-------|-------|-----|--------|
| VALUE : | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |
| NAME : | OP4 | OP3 | OP2 | OP1 | INPOS/OP0 | ALARM | BRAKE | RDY | ORGOUT |

1: Output signal operating

0: Output signal not operating

5. Parameter Setting

| Signal | Display | Description |
|-----------|---------|--|
| ORGOUT | 1 | Completely reach the origin point displayed |
| RDY | 1 | No Alarm, power good displayed. |
| BRAKE | 1 | Motor brake reset signal display. |
| ALARM | 1 | No Alarm displayed |
| INPOS/OP0 | 1 | Command position reached displayed/(Turret operation position reach display 0) |
| OP1 | 1 | (TURRET operation) Command position reached display 1 |
| OP2 | 1 | (TURRET operation) Command position reached display 2 |
| OP3 | 1 | (TURRET operation) Command position reached display 3 |
| OP4 | 1 | (TURRET operation) Command position reached display 4 |

The above examples are based on the current status of each signal. System operates in reverse if signals are in opposite status

5.11 Alarm Status Display (Alarm Status : ALS--)

| Menu | Menu title | Description |
|-------|-----------------|--|
| ALS01 | Alarm Display | Displays current alarms (In normal condition: displays "normal"). |
| ALS02 | Alarm Reset | Resets current alarms. |
| ALS03 | Alarm History | Displays the latest 10 alarms. |
| ALS04 | Alarm Reset All | Resets all alarm history stored in the Alarm History. |

[Details of ALARM displays (sub-menus)]

| Menu | Menu title | Cause |
|--------|------------|---|
| Normal | | Normal operating condition |
| AL-00 | EMER STOP | External ESTOP contact input turned OFF |
| AL-01 | OVER CURNT | Drive output terminal (U, V, W) short-circuited; output overcurrent |
| AL-02 | OVER VOLT | Input voltage excessiveness (greater than 280V); regeneration brake resistance burned; load GD ² excessive |
| AL-03 | OVER LOAD | Mechanical overload; motor miswiring |
| AL-04 | POWER FAIL | Main power disconnected when Servo is ON |
| AL-05 | LINE FAIL | Motor and encoder set value error, motor miswiring, and mechanical overload |

| | | |
|-----------------|------------|--|
| AL-06 | OVER SPEED | Gain excessiveness, menu set value error, excessive gravity load |
| AL-07 | FOLLOW ERR | Rapid deceleration/acceleration, gain set value error, command pulse frequency excessive (greater than 300 kpps), miswiring, mechanical overload |
| AL-08 | Output NC | Output (U, V, W) open phase |
| AL-09 | PPR ERROR | Encoder pulse level setting error |
| AL-10 | ABS DATA | Absolute value encoder data transmission error |
| AL-11 | ABS BATT | Battery level below 2.8V |
| AL-12 | ABS MDER | Absolute value encoder multi-rotation data transmission error |
| AL-13 | ORG ERR | Origin Search Err. |
| AL-14 | ERASE FAIL | Parameter Erase Err. |
| AL-15 | WRITE FAIL | Parameter Write Err. |
| AL-16 | PARA INIT | Parameter Initial Fail |
| Parameter Err 1 | | Unchangeable parameter input tried during servo ON, parameters locked |
| Parameter Err 2 | | Set value input error |

In case of an alarm, the alarm signal output contact(ALARM) is turned off and the motor stops by the action of the dynamic brake.

To reset the contents of current alarms, use the Alarm Reset (ALS02) menu, or use the input contact ALMRST (CN1-38) terminal.

The submenu of Alarm History (ALS03) includes Alarm 1, Alarm 2, Alarm 3, Alarm 4, Alarm 5, Alarm 6, Alarm 7, Alarm 8, Alarm 9, and Alarm 10 which are the past alarms. Alarm 1 indicates the latest alarm, while the remaining alarms indicates those which occurred previously.

To reset all past alarm history, use the menu Alarm Reset All (ALSO4). However, EMER STOP (AL-00) cannot be stored in the Alarm History (ALS03).

6. Operation Mode and How to use

6.1 An important point check and set items, when operation

Before servo operating, surely check and set the items below.

***** Servo and machines can be damaged by error setting.**

1) Where it is rightly chosen the form of purchase product.

| Title | Parameter | | Setting |
|---------------|-----------|---------------|--|
| | No. | Name | |
| Servo motor | P1-01 | Motor ID | Set ID number according to servo motor types. |
| Drive | P1-10 | Amp Type | Set ID number according to drive types. |
| Encoder | P1-11 | Encoder Type | Set ID number according to encoder signal types. |
| Encoder pulse | P1-12 | Encoder Pulse | Set encoder pulse number. |

2) Notify Brake reset sequence when using motor internal brake

| Title | Parameter | | Setting |
|--------------------------|-----------|------------|---|
| | No. | Name | |
| Speed of brake operation | P2-08 | Brake SPD | Set brake operation starting speed when stopping. |
| Time of brake operation | P2-09 | Brake Time | Operate brake after passing the set time when stopping. |

→ Check the brake operation parameter set whether there is error or not.

→ Check whether brake out contact was connected with drive unit.

→ Check the output voltage of brake drive unit.

3) Set proper gain according to the inertia of load

| Title | Parameter | | Setting |
|------------------------------|-----------|-----------------|-----------------|
| | No. | Name | |
| Position proportional gain | P2-01 | PC P Gain | Reference below |
| Speed loop proportional gain | P2-02 | SC LOOP Gain | Reference below |
| Speed integral | P2-03 | SC I TC | Reference below |
| Inertia ratio | P2-21 | Inertia Ratio | Reference below |
| Auto setting range | P2-22 | Autotune Range | Reference below |
| Auto setting ON/OFF | P2-23 | Autotune ON/OFF | Reference below |

a) How to auto-tuning

Auto-tuning only use in case of rotating motor over a fifty times make OFF after set during normal operation.

Set the range according to roughly inertia ratio.

| Inertia ratio | setting | Inertia ratio | setting |
|---------------|---------|---------------|---------|
| Unknown | 0 | 15-100 | 5 |
| 1-3 | 1 | 25-200 | 6 |
| 2-10 | 2 | 100-300 | 7 |
| 3-15 | 3 | 200-400 | 8 |
| 10-25 | 4 | 300-500 | 9 |

* Inertia ratio = (inertia of motor + load inertia)/motor inertia

→ If autotuning (P2-23) is ON and practice five times deceleration and acceleration operation inertia value is saved to P2-21.

→ If the value of inertia ratio is set make the autotuning OFF

b) How to gain tuning

→ Incase of knowing the inertia ratio, Input the inertia ratio passively.

→ Tune the below value according to the inertia ratio.

| Inertia ratio | 60,80 | 130 | Setting | | | |
|---------------|-------|-----|----------------------|-----------------|-------------------|----|
| | | | SC LOOP Gain (P2-02) | SC I TC (P2-03) | PC P Gain (P2-01) | |
| 1 | | | 500 | 20 | 6 | 50 |
| 2 | | | 350 | 30 | 9 | 35 |
| 3 | | | 290 | 35 | 11 | 29 |
| 5 | 1 | | 220 | 45 | 14 | 22 |
| 10 | 2 | | 160 | 60 | 19 | 16 |
| 20 | 3 | | 110 | 90 | 27 | 11 |
| 50 | 5 | | 70 | 140 | 42 | 7 |
| 100 | 10 | | 50 | 200 | 60 | 5 |
| | 20 | | 30 | 300 | 100 | 3 |


→ If the SC Loop gain is too low, vibration occurs and response becomes fast if it is high, but vibration occurs if the gain is excessively high. Response becomes fast if SC I TC is reduced, but overshoot occurs if it is reduced excessively. Position reaching time is shortened if the PC P Gain is increased; however, excessive gain may cause vibration and overshoot.

→ In case that happens noise by vibration in motor, tune FDELAY (P3-15). If FDELAY increase, noise is lessen, but it is stable that is used within SC I TC value.

→ If motor is unstable in above course, inquire technique department. That records parameter tuned is helpful.

6.2 How to operate absolute position

6.2.1 Rectangular coordinate operation



1) Set machine momentum

ex) In case of 1[mm] per two rotations : Move Motor [P7-01]=2 & move Mechanical [P7-02]=1

2) Set moving direction [P7-03]

In case of CW, Coordinates value increases : 0

In case of CCW, Coordinates value increases : 1

3) Set MPG operation

In case of using MPG, can only use the position coordinates till 0-15, MPG signal applied to COMSEL4 and coordinates selection limited four input contact of COMSEL0-COMSEL3.


4) How to use CCWLIM, CWLIM, CCWJOG & CWJOG contact

In case of using CCWLIM, CWLIM, CCWJOG & CWJOG contact in simultaneously, set the parameter P8-03 = "2". And only use the position coordinates till 0-3 CCWJOG, CWJOG signals applied to COMSEL2, COMSEL3 and coordinates selection limited two input contact of COMSEL0-COMSEL1.


5) Main application field

32 point operating I/O selection in an axis or multiple axes which don't use interpolation function.

ex) Application to two Robots (In case of simple coordinate movement operation: Can operation till 32 points)



6.2.2 Rotary coordinate operation



1) Set machine momentum

ex) In case of 360 degree per ten rotations : Motor revolution quantity [P7-01]=10 & Device moving quantity [P7-02]=360

2) Set moving direction [P7-03]

In case of CW, Coordinates value increases : 0

In case of CCW, Coordinates value increases : 1

3) Set MPG operation


In case of using MPG, can only use the position coordinates till 0-15 MPG signal applied to COMSEL4 and coordinates selection limited four input contact of COMSEL0-COMSEL3.

4) How to use CCWLIM, CWLIM, CCWJOG & CWJOG contact

In case of using CCWLIM, CWLIM, CCWJOG & CWJOG contact in simultaneously, set the parameter P8-03 = "2". And only use the position coordinates till 0-3 CCWJOG, CWJOG signals applied to COMSEL2, COMSEL3 and coordinates selection limited two input contact of COMSEL0-COMSEL1.

5) Short distance discrimination function.


In case that becomes the position after one cycle and regardless of rotation direction in machine structure, discriminate short distance and make rotation operation on such direction.



6) Angle division stop in JOG.[P7-07]

Although stop command is putted during JOG operation mode at optional angle, stop at set value angle division position.

ex) In case of [P7-07]=45




7) Main application field

Do the turret of building machine or addition axis and all sorts INDEX machine angle division operation.

6.3 How to use relative position operation.

6.3.1 Roll Feeder operation



1) Set machine momentum

ex) In case of 2[mm] per rotation : Motor revolution quantity [P7-01]=5 & Device moving quantity[P7-02]=10


2) Set moving direction[P7-03]

In case of CW, Coordinates value increases : 0

In case of CCW, Coordinates value increases : 1

3) Position completion signal: INPOS(Completion of position decision) : 48 No. terminal of CN1

As a set the position decision range [P4-02] can display completion signal within fixed range.



4) Continuous stopping time[P8-02]


In case of auto operation(continuous operation in order) can set stop time of each step.

5) Main application field

Input transportation quantity of maximum 32 in parameter at all sorts, Feeder and conveyer transportation device, Manual operation mode : In case of START Contact=ON after select the I/O contact, transport operation equivalent to relevant quantity

Auto operation mode : in case of START contact=ON, continuous sequential operation.

6.4 How to use sequential operation.



1) Set machine momentum

ex) In case of 2[mm] pulse per rotation : Motor revolution quantity [P7-01]=5 & Device moving quantity[P7-02]=10

2) Set moving direction[P7-03]

In case of CW, Coordinates value increases : 0

In case of CCW, Coordinates value increases : 1

3) Position completion signal: INPOS(Completion of position decision) : 46 No. terminal of CN1

As a set the position decision range [P4-02] can display completion signal within fixed range.



4) Continuous stopping time[P8-02]

In case of auto operation(continuous operation in order) can set stop time of each step.


5) Main application field

In an axis or multiple axes machine which don't use interpolation function. input absolute position value in parameters and execute sequential operation by START contact of ON


Manual operation mode : START contact=ON, 1 step operation

Auto operation mode : START contact=ON, continuously sequential operation

ex) Application to two axes Robot (Incase of simple coordinates movement operation)



6.4.2 Rotary Coordinate Operation



1) Set machine momentum

ex) In case of 360 degree per ten rotations : Motor revolution quantity [P7-01]=10 & Device moving quantity[P7-02]=360


2) Set moving direction[P7-03]

In case of CW, Coordinates value increases : 0

In case of CCW, Coordinates value increases : 1

3) Position completion signal: INPOS(Completion of position decision) : 46 No. terminal of CN1

As a set the position decision range [P4-02] can display completion signal within fixed range.



4) Continuous stopping time[P8-02]

In case of auto operation(continuous operation in order) can set stop time of each step.

5) Main application field

Input absolute position value in parameter at all sorts INDEX machine, respectively and sequential operation is executed by START contact of ON,

Manual operation mode : START contact=ON; 1 step operation

Auto operation mode : START contact=ON, continuously sequential operation

6.5 Setting of position, input and output

| Parameter | | | Input | | | | | Output | | | | |
|-----------|----------------|---------|-------|---|---|---|---|--------|---|---|---|---|
| No. | | Initial | 0 | 1 | 2 | 3 | 4 | 0 | 1 | 2 | 3 | 4 |
| P5-01 | Position CMD0 | 10 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| P5-02 | Position CMD1 | 20 | 1 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 |
| P5-03 | Position CMD2 | 30 | 0 | 1 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 |
| P5-04 | Position CMD3 | 40 | 1 | 1 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | 0 |
| P5-05 | Position CMD4 | 50 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 1 | 0 | 0 |
| P5-06 | Position CMD5 | 60 | 1 | 0 | 1 | 0 | 0 | 1 | 0 | 1 | 0 | 0 |
| P5-07 | Position CMD6 | 70 | 0 | 1 | 1 | 0 | 0 | 0 | 1 | 1 | 0 | 0 |
| P5-08 | Position CMD7 | 80 | 1 | 1 | 1 | 0 | 0 | 1 | 1 | 1 | 0 | 0 |
| P5-09 | Position CMD8 | 90 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 1 | 0 |
| P5-10 | Position CMD9 | 100 | 1 | 0 | 0 | 1 | 0 | 1 | 0 | 0 | 1 | 0 |
| P5-11 | Position CMD10 | 110 | 0 | 1 | 0 | 1 | 0 | 0 | 1 | 0 | 1 | 0 |
| P5-12 | Position CMD11 | 120 | 1 | 1 | 0 | 1 | 0 | 1 | 1 | 0 | 1 | 0 |
| P5-13 | Position CMD12 | 130 | 0 | 0 | 1 | 1 | 0 | 0 | 0 | 1 | 1 | 0 |
| P5-14 | Position CMD13 | 140 | 1 | 0 | 1 | 1 | 0 | 1 | 0 | 1 | 1 | 0 |
| P5-15 | Position CMD14 | 150 | 0 | 1 | 1 | 1 | 0 | 0 | 1 | 1 | 1 | 0 |
| P5-16 | Position CMD15 | 160 | 1 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 1 | 0 |
| P5-17 | Position CMD16 | 170 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | 1 |
| P5-18 | Position CMD17 | 180 | 1 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | 0 | 1 |
| P5-19 | Position CMD18 | 190 | 0 | 1 | 0 | 0 | 1 | 0 | 1 | 0 | 0 | 1 |
| P5-20 | Position CMD19 | 200 | 1 | 1 | 0 | 0 | 1 | 1 | 1 | 0 | 0 | 1 |
| P5-21 | Position CMD20 | 210 | 0 | 0 | 1 | 0 | 1 | 0 | 0 | 1 | 0 | 1 |
| P5-22 | Position CMD21 | 220 | 1 | 0 | 1 | 0 | 1 | 1 | 0 | 1 | 0 | 1 |
| P5-23 | Position CMD22 | 230 | 0 | 1 | 1 | 0 | 1 | 0 | 1 | 1 | 0 | 1 |
| P5-24 | Position CMD23 | 240 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 1 | 0 | 0 |
| P5-25 | Position CMD24 | 250 | 0 | 0 | 0 | 1 | 1 | 0 | 0 | 0 | 1 | 1 |
| P5-26 | Position CMD25 | 260 | 1 | 0 | 0 | 1 | 1 | 1 | 0 | 0 | 1 | 1 |
| P5-27 | Position CMD26 | 270 | 0 | 1 | 0 | 1 | 1 | 0 | 1 | 0 | 1 | 1 |
| P5-28 | Position CMD27 | 280 | 1 | 1 | 0 | 1 | 1 | 1 | 1 | 0 | 1 | 1 |
| P5-29 | Position CMD28 | 290 | 0 | 0 | 1 | 1 | 1 | 0 | 0 | 1 | 1 | 1 |
| P5-30 | Position CMD29 | 300 | 1 | 0 | 1 | 1 | 1 | 1 | 0 | 1 | 1 | 1 |
| P5-31 | Position CMD30 | 310 | 0 | 1 | 1 | 1 | 1 | 0 | 1 | 1 | 1 | 1 |
| P5-32 | Position CMD31 | 320 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |

Note1) 0: contract OFF, 1: Contact On

Note2) can only use till P5-01-P5-16 when use MPG.

Note3) can only use till P5-01-P5-04 when P8-03="2".

6.6 Origin Operation

| Origin Mode[P8-09] | | Origin Operation |
|--------------------|--|---|
| No. | Origin Signal | |
| (0) | Not | Not using Origin Operation |
| (1) (2) | Using CW Limit | |
| (3) (4) | Using CCW Limit | |
| (5) (6) | Using CW direction and Origin DOG | <p>● If meets CW Limit signal prior to origin DOG signal, ORG Error is occurred.</p> |
| (7) (8) | Using CW direction and Origin DOG | <p>● If meets CCW Limit signal prior to origin DOG signal, ORG Error is occurred.</p> |
| (9) (10) | Using CW CCW direction (CW Limit) and origin DOG | |

| Origin Mode[P8-09] | | Origin Operation |
|--------------------|--|--|
| No. | Origin Signal | |
| (11) (12) | Using CCW CW direction (CCW Limit) and origin DOG | <p>Z Pulse Origin DOG CCW Limit</p> <p>ORG Speed 0[P6-01] (11) (12)</p> <p>ORG Speed 1[P6-02]</p> <p>ORG Offset[P6-04]</p> |
| (13) (14) | Using CW Damper | <p>CW Damper Z Pulse</p> <p>ORG Speed 0[P6-01] (13)</p> <p>ORG Speed 1[P6-02]</p> <p>ORG Offset[P6-04]</p> |
| (15) (16) | Using CCW Damper | <p>Z Pulse CCW Damper</p> <p>ORG Speed 0[P6-01] (15) (16)</p> <p>ORG Speed 1[P6-02]</p> <p>ORG Offset[P6-04]</p> |
| (17) (18) | Using CCW CW direction (Z Phase) | <p>Z Pulse</p> <p>ORG Speed 1[P6-02] (17)</p> <p>ORG Speed 0[P6-01]</p> <p>ORG Offset[P6-04]</p> |
| (19) (20) | Using CW CCW direction (Z Phase) | <p>Z Pulse</p> <p>ORG Speed 1[P6-02] (19) (20)</p> <p>ORG Offset[P6-04]</p> |
| (21) (22) | Using CCW CW direction and Origin DOG(Without Z Phase) | <p>Origin DOG</p> <p>ORG Speed 0[P6-01] (21)</p> <p>ORG Speed 1[P6-02]</p> <p>ORG Offset[P6-04]</p> |
| (23) (24) | Using CW CCW direction and Origin DOG(Without Z Phase) | <p>Origin DOG</p> <p>ORG Speed 0[P6-01] (23) (24)</p> <p>ORG Speed 1[P6-02]</p> <p>ORG Offset[P6-04]</p> |

Note1) Can use origin speed of two for exact and quick origin execution

(ORG Speed 0[P6-01], ORG Speed 0[P6-02])


Note2) Can specify origin equivalent to the position which z phase position fixed distance by using ORG Offset[P6-04]

Note3) In case of using Damper(13-16) set torque in ratings torque ratio(%) for recognition in collision with damper.

Note4) When servo in ON, in case that do origin execution, set automatic origin operation[P8-08]

6.7 How to JOG operation

JOG mode is comprised of subordinate menu of position coordinates input(position command mode P5--) and, Jog mode is enable the digital loader without outer contact signal.



6.8 How to use Monitor

The servo's internal speed command and torque, and the feedback motor speed can be monitored from outside through the analog output (MONIT1) and (MONIT2). The range of output voltage is -4[V] - 4[V]. The following are the parameters related to the use of the motor

| Menu | Menu name | Description | Unit | Range | Default |
|-------|-----------------|---------------|------|-------|---------|
| P2-10 | Monitor1 Select | Set monitor 1 | | 0-3 | 0 |
| P2-14 | Monitor2 Select | Set monitor 2 | | 0-3 | 1 |

Set parameter to be output on the monitor
(0: position 1: position error, 2: speed 3:torque)

| Menu | Menu name | Description | Unit | Range | Default |
|-------|--------------|---------------|------|-------|---------|
| P2-11 | Monitor1 ABS | Monitor1 mode | | 0,1 | 0 |
| P2-15 | Monitor2 ABS | Monitor2 mode | | 0,1 | 0 |

0: Output codes by type
1: Output absolute values

| Menu | Menu name | Description | Unit | Range | Default |
|-------|----------------|------------------------|----------|-------|---------|
| P2-12 | Monitor1 Scale | Monitor1 magnification | multiple | 1-20 | 1 |
| P2-16 | Monitor2 Scale | Monitor2 magnification | multiple | 1-20 | 0 |


In case that observation is difficult because analog output value is small, it is to see that variable multiply pertinent multiple.
For example, in case of input 3, variable size enlarges three times.
[Basis magnification] Position : 99999.9/4[V] ,
Speed : Maximum speed/4[V] &
torque : (3*rating torque)/4[V]

| Menu | Menu name | Description | Unit | Range | Default |
|-------|-----------------|-----------------|------|----------|---------|
| P2-13 | Monitor1 offset | Monitor1 offset | % | -100-100 | 0 |
| P2-17 | Monitor2 offset | Monitor2 offset | % | -100-100 | 0 |


This is used to output values by applying appropriate offset to the analog output values. This is to enable adjustment of the values output on 0[V] potential by applying offset to the monitor output. Unit used is [%], and the maximum value is 100 [%]. If the speed is output assuming the maximum speed as being 5000[rpm], 1000[rpm], 20[%] of 5,000, is displayed on 0[V] when offset 20 is loaded.

Monitor outputs according to the parameter set values are as follows. As the method of using monitor 1 and monitor 2 is the same, the following figures show outputs of monitor 1 only.

(1) In case of [Monitor 1 ABS (P2-12)] = 0 (2) In case of [Monitor 1 ABS (P2-12)] = 1



| | Speed, speed command | Torque |
|--------|---|--|
| Max | $1.25 \times \text{maximum speed}$ [Monitor1 Scale (P2-12)] | $1.25 \times 3 \text{ times rated torque}$ [Monitor1 Scale (P2-12)] |
| Offset | Maximum speed $\times \frac{[\text{Monitor1 offset (P2-13)}]}{100}$ | $(3 \text{ times rated torque}) \times \frac{[\text{Monitor1 offset (P2-13)}]}{100}$ |



7. Maintenance and Inspection

The servo drive need not be checked and maintained on a daily basis as it uses highly reliable parts, but inspect it at least once a year. The brushless servo motor is semi-permanent. However, check it periodically for signs of abnormal noise or vibration.

7.1 Caution

1. When checking motor voltage: As the voltage applied to the motor from the servo amplifier is PWM controlled pulse train, wave form of pulse phase is displayed. There may be significant difference in indicator value depending on types of electric and electronic meters. Always use rectifier type voltmeter to obtain accurate measurement.
2. When checking motor current: The pulse wave form is smoothed to sine wave to a certain degree by the motor reactance. Connect and use a moving-iron type ampere meter.
3. When checking power: Use an electrodynamics type 3-phase watt-meter.
4. Other meters: Use oscilloscopes or digital voltmeter without letting them make contact with the ground. Use meters with input current of 1 mA or less.

7.2 Inspection Items

(Caution !!) Charged voltage may remain in the smoothing condenser creating an element of danger when inspecting the drive. Turn off power and wait for approximately 10 minutes before starting, inspection.

1. Check the inside of the machine for cable chips, dust or other debris and clean it up.
2. Check the terminal screws for looseness. Tighten them if necessary.
3. Check parts for defects (discoloration caused by heat, damage or disconnection).
4. Use high resistance range of the tester to test the conductivity of the control circuit.
Do not use Megger or Buzzer.
5. Check the cooling fan for normal operation.
6. Check for abnormal noise (motor bearing, brakes)
7. Check cables for signs of damage or defects (particularly the detector cables). Check periodically during operation.
8. Check the load connection axis for center deviation, and make necessary adjustment.

7.3 Replacing Parts

The following parts undergo aging process as time passes due to mechanical friction or the characteristics of the material used, leading to the deterioration of equipment performance or breakdown. Check the parts periodically and replace them, if necessary.

1. **Smoothing condenser:** The characteristics become aged due to the effects of ripple current. The operating life of the condenser varies significantly depending on ambient temperature and operating conditions. When used continuously in normal environment, its standard life span is 10 years. The condenser becomes aged fast during a specific period. Inspect it at least once a year (it is desirable to conduct inspection semi-annually in case the life span is nearing the exhaustion point).

For judgement criteria, visually check:

- a. Case status: Check if the sides and bottom of the case are expanded.
 - b. Cover plate: Check for significant expansion, severe cracks or damage.
 - c. Explosion-proof valve: Check for significant expansion or wear.
 - d. Check periodically the external condition for cracks, tear, discoloration and water-leakage. If the rated capacity of the condenser drops to 85% or less, it indicates life span has exhausted.
2. **Relays:** Inadequate contact may occur due to contact wear resulting from switching current. The relay wear condition is affected by the power capacity. The standard life span is 100,000 accumulated switching (switching life) operations.
 3. **Motor bearing:** Replace bearing when it is used for 20,000-30,000 hours under rated speed and rated load. The motor bearing condition is dependent upon the operating conditions. Replace the bearing if abnormal noise or vibration is discovered.

[Standard replacement period]

| Parts | Standard replacement period | How to replace |
|--|------------------------------------|---|
| Smoothing condenser | 7-8 years | Replace with new parts (Decide after check) |
| Relays | - | Decide after check |
| Fuses | 10 year | Replace with new ones |
| Motor bearing | - | Decide after check |
| Aluminum electrolytic condenser on PCB | 5 years | Replace with new PCB (Decide after check) |

7.4 Maintenance

7.4.1 Motor

If the motor is not used immediately, preserve it in the following manner.

- 1) Store the motor in a clean and dry place.

| Ambient temperature | Ambient humidity |
|---------------------|-------------------|
| -15 ~ +70 | Less than 90 % RH |

(Caution !) Must be free of dewing or freezing.

- 2) If the motor is stored outside or in a place with humidity, cover it with an appropriate type of cover to prevent infiltration of rain or dust.
- 3) If the motor is to be stored for a long period of time after use, apply rust-proof agent on the shaft or on slide ways to prevent rust.

7.4.2 Servo drive

It is not desirable to leave the servo drive unused for a long period of time. If the servo drive is not used immediately, store it in the following manner.

- 1) Store the drive in a clean and dry place.

| Ambient temperature | Ambient humidity |
|---------------------|-------------------|
| -15 ~ +65 | Less than 90 % RH |

(Caution !) Must be free of dewing or freezing.

Ambient temperature applies to short period of time, such as during transporting.

- 2) As the drive is in open structure, exercise caution not to allow dust to be accumulated.

8. Troubleshooting

In case an error occurs during operation, take the following steps. If taking such steps does not correct errors, contact our service center.

8.1 Servo Motor

Actions to be taken in case of errors

| Symptom | Cause | Inspection | Corrective action |
|------------------------|---|---|--|
| Motor does not start | Parameter setting is incorrect | Check parameters related to motor, encoder, encoder type and control mode. | Reset parameters. (See sections 5 and 6) |
| | Overloaded | Check machine running condition. | Readjust mechanical systems. |
| | Motor defective | Check motor lead terminal with a tester. | If voltage is correct, replace motor. |
| | Screws loosened | Check the screws. | Retighten loose screws. |
| | Incorrect external wiring, or cable disconnected | Check the motor and encoder wiring. | Rewire. Replace cable. |
| Motor running unstable | Encoder defective | Check the output wave form. | Replace encoder. (Use A/S service) |
| | Defective connection | Check connection of the motor lead terminal. | Repair defective part. |
| | Input voltage low | Check drive input voltage. | Change power supply. |
| Motor overheated | Overloaded | Check machine condition. | Remove foreign material from the rotator and lubricate (or grease) it. |
| | Ambient temperature high | Check the motor ambient temperature. (Should be lower than 40) | Change heat-shield structure. |
| | Motor surface stained | Check motor surface for attached foreign materials. | Clean the surface of the motor. |
| | Overloaded | Check the load rate of the drive. Check acceleration/deceleration cycle. | Reduce load. Increase acceleration/deceleration time |
| Abnormal noise | Magnetic power deteriorated | Check counter electromotive voltage and wave form. | Replace motor. |
| | Defective coupling | Check the tightness of the coupling screws and the concentricity of joints. | Readjust coupling. |
| | Defective bearing | Check the bearing for vibration or abnormal noise. | Contact LG service center. |
| | Parameter misset (inertia ratio, gain, time constant) | Check control parameters. | See Chapter 6. Parameter Setting. |

8.2 Servo drive


If an alarm occurs, error signal output contact (Alarm) is turned OFF, and the motor stops by the action of dynamic brake.

Actions to be taken in case of an alarm

| Screen display | Cause | Corrective action |
|---------------------|--|---|
| Normal | | |
| AL-00 EMER STOP | External ESTOP contact input turned OFF. | Check external DC 24V power supply. Check if the ESTOP contact is turned ON. |
| AL-01 OVER CURNT | Servo drive output terminal (U, V, W) short-circuited, output overcurrent. | Check the output terminal wiring. Restart after resetting alarm. Replace drive if O.C. continues. |
| AL-02 OVER VOLT | Input voltage excessive (greater than 280V). Regeneration control resistance burned. Load GD ² excessive. | Use input voltage lower than 230V. Replace control resistance, increase acceleration/deceleration time. Replace servo drive. |
| AL-03 OVER LOAD | Mechanical overload. Motor miswiring. | Check load condition. Check the motor and encoder wiring. |
| AL-04 POWER FAIL | Main power shut off during Servo ON status. | Check the 3-phase main power supply (R, S, T) input status. |
| AL-05 LINE FAIL | Motor and encoder set value error, motor and encoder miswiring, defective encoder, mechanical overload. | Check motor and encoder wiring and set values. Remove excessive load. |
| AL-06 OVER SPEED | Excessive gain, parameter set value error, excessive gravity load. | Adjust gain. Check parameters (P3-14). Remove excessive gravity load. |
| AL-07 FOLLOW ERR | Rapid acceleration/deceleration, gain set value error, command pulse frequency excessive (higher than 300 kpps), miswiring, mechanical overload. | Adjust position gain, increase menu (P4-03) set value, adjust command pulse frequency, check motor and encoder wiring. |
| AL-08 OUTPUT NC | Output (U, V, W) open phase. | Check motor wiring. Replace servo drive. |
| AL-09 PPR ERROR | No. of encoder pulse set error. | Set the number of encoder pulse (P1-12) accurately. |

| Screen display | Cause | Corrective action |
|---------------------|--|--|
| AL-10 ABS DATA | Absolute value encoder data transmission error. | Reset and retransmit the absolute value encoder data. |
| AL-11 ABS BATT | Battery voltage drops below 2.8V. | Replace battery (3.6V). |
| AL-12 ABS MDER | ABS encoder multi-rotation data transmission error. | Reset and retransmit the absolute value encoder data. |
| AL-13 ORG ERROR | When 5~8 origin rule search, meet limit signal in out of Dog portion. | Reset and Origin search to meet Limit signal in Dog portion. |
| AL-14 ERASE FAIL | Parameter Erase Error | Check the Power(Noise) and reset the power |
| AL-15 WRITE FAIL | Parameter Write Error | Check the Power(Noise) and reset the power |
| AL-16 PARA INIT | Parameter Initial Error | Check the Loader cable/connector and reset the power |
| Parameter Err 1 | Input of parameters, which cannot be changed, is attempted during Servo ON. Parameters locked. | Turn OFF the servo and change the set value. Reset parameter locking menu (P1-13). |
| Parameter Err 2 | Set value input error. | Input values within the set range. |


[Overload characteristic curves of Servo Drive]



| Rated current (%) | Overload operating time | | |
|-------------------|-------------------------|------|-----------|
| | Min. | Max. | Set value |
| 100 | | | |
| 120 | | | |
| 150 | 300 | 1500 | 760 |
| 200 | 60 | 150 | 107 |
| 250 | 20 | 40 | 30 |
| 300 | 6 | 15 | 7 |

9. External View

9.1 External Dimensions of AC Servo Drive




| Product | A | B | C | D | E | F | G | Weight [Kg] | Cooling system | Outline Drawing |
|-----------|-----|------|-----|-------|-----|-----|-----|-------------|----------------------|-----------------|
| FDA6001C | 164 | 5 | 175 | 130 | 60 | 5.5 | - | 1.0 | Self-cooling | A |
| FDA6002C | 164 | 5 | 175 | 130 | 60 | 5.5 | - | 1.0 | | |
| FDA6004C | 164 | 5 | 175 | 130 | 77 | 5.5 | 63 | 1.3 | | |
| FDA6005C | 200 | 5 | 210 | 184 | 95 | 5.5 | 80 | 2.1 | | |
| FDA6010C | 200 | 5 | 210 | 184 | 95 | 5.5 | 80 | 2.1 | Forced cooling (Fan) | B |
| FDA6012C | 200 | 5 | 210 | 184 | 95 | 5.5 | 80 | 2.3 | | |
| FDA6015C | 272 | 6 | 284 | 218 | 135 | 6.0 | 111 | 4.5 | | C |
| FDA6020C | 272 | 6 | 284 | 218 | 135 | 6.0 | 111 | 4.8 | | |
| FDA6030C | 272 | 6 | 284 | 218 | 135 | 6.0 | 111 | 4.9 | | |
| FDA6045C | 272 | 6 | 284 | 218 | 135 | 6.0 | 111 | 5.0 | D | D |
| FDA6075CN | 334 | 8 | 350 | 236 | 240 | 7.0 | 180 | 15 | | |
| FDA6110CN | 434 | 12.5 | 450 | 280.5 | 260 | 7.0 | 200 | 23 | | E |
| FDA6150CN | 434 | 12.5 | 450 | 280.5 | 260 | 7.0 | 200 | 24 | | |


9.2 External Dimensions of AC Servo Motor

9.2.1 Flange 60 Series

Standard type



Brake type




| Model | L | LM | CB1 | CB2 | Weight(kg) |
|-------------|----------|----------|----------|----------|------------|
| FMA-CN01(B) | 115(155) | 85(125) | 44(44) | 57(97) | 0.85(1.4) |
| FMA-CN02(B) | 129(169) | 99(139) | 58(58) | 71(111) | 1.14(1.7) |
| FMA-CN03(B) | 143(183) | 113(153) | 72(72) | 85(125) | 1.43(2.0) |
| FMA-CN04(B) | 157(197) | 127(167) | 86(86) | 99(139) | 1.73(2.3) |
| FMA-CN05(B) | 171(211) | 141(181) | 100(100) | 113(153) | 2.03(2.6) |


* Figures in () indicate brake-attached type.

* Use DC 24 V for brake input power supply.

* In case of applying absolute encoder, Motor length is extended 15mm.




MOTOR CONNECTOR DIAGRAM




ENCODER CONNECTOR DIAGRAM

9.2.2 Flange 80 Series

Standard type



Brake type





| Model | External dimensions | | | | | Key dimensions | | | Weight |
|-------------|---------------------|----------|----------|------|-------|----------------|----|----|----------|
| | L | LL | LM | CB1 | CB2 | S | LS | LK | |
| CN04A, KN03 | 147(174) | 112(139) | 76(103) | (63) | (113) | 14 | 35 | 20 | 2.1(2.9) |
| CN06, KN05 | 171(198) | 131(158) | 95(122) | (63) | (132) | 16 | 40 | 25 | 2.6(3.3) |
| CN08, KN06 | 193(219) | 153(179) | 117(143) | (63) | (153) | 16 | 40 | 25 | 3.1(3.9) |
| CN10, KN07 | 213(246) | 173(206) | 137(170) | (70) | (180) | 16 | 40 | 25 | 3.7(4.6) |

* Figures in () indicate brake-attached type.


* Use DC 24V for brake input power supply.

* In case of applying absolute encoder, Motor length is extended 15mm.




MOTOR CONNECTOR DIAGRAM

| TYPE | SIGNAL | PIN No | SIGNAL | PIN No |
|-------------|--------|--------|--------|--------|
| INCREMENTAL | A | 1 | V | 9 |
| | Ā | 2 | V̄ | 10 |
| | B | 3 | W | 11 |
| | B̄ | 4 | W̄ | 12 |
| | Z | 5 | DC+5V | 13 |
| | Z̄ | 6 | DV | 14 |
| | U | 7 | SHIELD | 15 |
| | Ū | 8 | | |



ENCODER CONNECTOR DIAGRAM

9.2.3 Flange 130 Series




(Dotted lines indicate position of brake-attached connectors)

| Model | | | | External dimensions | | | | | Key dimensions | | | | Weight |
|-------|-------|------|------|---------------------|--------------|--------------|-------------|--------------|----------------|---|-----|---|----------------|
| | | | | L | LL | LM | CB1 | CB2 | S | T | U | W | |
| | | TF05 | LF03 | 269 (315) | 211 (257) | 160 (206) | 132 (53) | 180 (226) | 19 | 5 | 3 | 5 | 8.2 (10.4) |
| | KF08 | | | 285 (325) | 227 (267) | 176 (216) | 148 (53) | 196 (236) | 19 | 5 | 3 | 5 | 8.8 (11.0) |
| | KF10 | TF09 | LF06 | 325 (365) | 267 (307) | 216 (256) | 188 (53) | 236 (276) | 19 | 5 | 3 | 5 | 11.6 (13.8) |
| | KF15 | TF13 | LF09 | 385 (425) | 327 (367) | 276 (316) | 248 (53) | 296 (336) | 22 | 6 | 3.5 | 6 | 15.8 (18.0) |
| CN09 | KN06A | TN05 | LN03 | 207 (250) | 149 (192) | 98 (141) | 70 (71) | 118 (161) | 19 | 5 | 3 | 5 | 5.5 (7.7) |
| CN15 | KN11 | TN09 | LN06 | 231 (274) | 173 (216) | 122 (165) | 94 (71) | 142 (185) | 19 | 5 | 3 | 5 | 7.0 (9.2) |
| CN22 | KN16 | TN13 | LN09 | 255 (298) | 197 (240) | 146 (189) | 118 (71) | 166 (209) | 22 | 6 | 3.5 | 6 | 8.5 (10.7) |
| CN30 | KN22 | TN17 | LN12 | 279 (322) | 221 (264) | 170 (213) | 142 (71) | 190 (233) | 22 | 6 | 3.5 | 6 | 10.0 (12.2) |

* Figures in () indicate brake-attached type.


* Use DC 90V for brake input power supply.



MS3102A20-4P (STANDARD TYPE) MS3102A20-15P (BRAKE TYPE)

| Item | Lead Wire Marking | PIN No. |
|-------|----------------------|------------|
| Motor | U | A |
| | V | B |
| | W | C |
| | Ground | D |
| Brake | + | E |
| | - | F |

Motor Cable Connector Diagram




MS3102A20-29P

| Encoder Signal | PIN No. | Encoder Signal | PIN No. |
|----------------|---------|----------------|---------|
| A | A | U | K |
| \bar{A} | B | \bar{U} | L |
| B | C | V | M |
| \bar{B} | D | \bar{V} | N |
| Z | E | W | P |
| \bar{Z} | F | \bar{W} | R |
| OV | G | SHIELD | J |
| +5V | H | | |


Encoder Cable Connector Diagram

9.2.4 Flange 180 Series

Straight Shaft(Standard) Type (Dotted lines indicate position of brake-attached connectors)




Taper Shaft(Standard) Type (Dotted lines indicate position of brake-attached connectors)



| Model | | | | External dimensions | | | | | | Key dimensions | | | | Weight |
|-------|-------|------|-------|---------------------|--------------|--------------|-------------|--------------|-----|----------------|---|---|----|----------------|
| L | LL | LM | CB1 | CB2 | CB3 | S | T | U | W | | | | | |
| CN30A | KN22A | TN20 | LN12A | 265 (332) | 186 (253) | 135 (202) | 102 (96) | 156 (223) | 138 | 35 | 5 | 3 | 5 | 12.9 (18.5) |
| | KN35 | TN30 | LN20 | 300 (367) | 221 (288) | 170 (237) | 137 (96) | 191 (258) | 138 | 35 | 8 | 5 | 10 | 18.2 (24.0) |
| CN50A | | | | 310 (377) | 231 (298) | 180 (247) | 147 (96) | 201 (268) | 138 | 35 | 8 | 5 | 10 | 19.9 (25.7) |
| | KN55 | TN44 | LN30 | 350 (417) | 271 (338) | 220 (287) | 187 (96) | 241 (308) | 138 | 35 | 8 | 5 | 10 | 26.8 (32.5) |
| | | | LN40 | 410 (477) | 331 (398) | 280 (347) | 247 (96) | 301 (368) | 138 | 35 | 8 | 5 | 10 | 36.1 (41.8) |
| | | | TN75 | 461 (527) | 382 (448) | 331 (397) | 298 (96) | 352 (418) | 147 | 35 | 8 | 5 | 10 | 45.7 (51.4) |
| | KF22 | TF20 | LF12 | 347 (421) | 268 (342) | 217 (291) | 181 (96) | 238 (312) | 138 | 35 | 8 | 5 | 10 | 17.2 (24.7) |
| | KF35 | TF30 | LF20 | 407 (476) | 328 (397) | 277 (346) | 241 (96) | 298 (367) | 138 | 35 | 8 | 5 | 10 | 27.4 (34.9) |
| | KF50 | TF44 | LF30 | 507 (571) | 428 (492) | 377 (441) | 341 (96) | 398 (462) | 138 | 35 | 8 | 5 | 10 | 38.3 (45.8) |


*) Figures in () indicate brake-attached type. *) Use DC 90V for brake input power supply. *) In case of Taper shaft, shaft length is shorted

9.2mm.



Motor Cable Connector Diagram


| Item | Lead Wire Marking | PIN No. |
|-------|-------------------|---------|
| Motor | U | A |
| | V | B |
| | W | C |
| | Ground | D |
| Brake | + | E |
| | - | F |



Encoder Cable Connector Diagram


| Encoder Signal | PIN No. | Encoder Signal | PIN No. |
|----------------|---------|----------------|---------|
| A | A | U | K |
| \bar{A} | B | \bar{U} | L |
| B | C | V | M |
| \bar{B} | D | \bar{V} | N |
| Z | E | W | P |
| \bar{Z} | F | \bar{W} | R |
| OV | G | SHIELD | J |
| +5V | H | | |

9.2.5 Flange 220 Series



Straight Shaft(standard) Type (Dotted lines indicate position of brake-attached connectors)

| Model | External dimensions | | | | | | Key dimensions | | | | Weight |
|-------|---------------------|-----|-------|---------|---------|----|----------------|----|---|----|--------|
| | L | LL | LM | CB 1 | CB 2 | LK | S | T | U | W | |
| TN110 | 556 | 440 | 388.5 | 343 | 410 | 98 | 55 | 10 | 6 | 16 | 84 |
| TN150 | 461 | 345 | 293.5 | 348 | 335 | 90 | 42 | 8 | 5 | 12 | 59 |




< Incremental Encoder Connector Diagram>

10. Specifications of options

10.1 AC servo motor cable specifications


10.1.1 Encoder signal cable (Flange 60, 80 Series)



Order code(FCA_)

| Flange | Flexible type | | | | Non-flexible type | | | |
|--------|---------------|-------|-------|-------|-------------------|-------|-------|-------|
| | 3m | 5m | 10m | 20m | 3m | 5m | 10m | 20m |
| 60,80 | EA03F | EA05F | EA10F | EA20F | EA03N | EA05N | EA10N | EA20N |


10.1.2 Encoder signal cable (Flange 130,180 Series)



Order code(FCA_)

| Flange | Flexible type | | | | Non-flexible type | | | |
|-------------|---------------|-------|-------|-------|-------------------|-------|-------|-------|
| | 3m | 5m | 10m | 20m | 3m | 5m | 10m | 20m |
| 130,180,220 | FC03F | FC05F | FC10F | FC20F | FC03N | FC05N | FC10N | FC20N |


10.1.3 Power cable for motor (Flange 60,80 Series)



Order code(FCA-)

| Flange | Type | Flexible type | | | | Non-flexible type | | | |
|--------|----------|---------------|-------|-------|-------|-------------------|-------|-------|-------|
| | | 3m | 5m | 10m | 20m | 3m | 5m | 10m | 20m |
| 60 | Standard | SA03F | SA05F | SA10F | SA20F | SA03N | SA05N | SA10N | SA20N |
| | Brake | BA03F | BA05F | BA10F | BA20F | BA03N | BA05N | BA10N | BA20N |
| 80 | Standard | SB03F | SB05F | SB10F | SB20F | SB03N | SB05N | SB10N | SB20N |
| | Brake | BB03F | BB05F | BB10F | BB20F | BB03N | BB05N | BB10N | BB20N |

10.1.4 Power cable for motor (Flange 130,180 Series)




Order code(FCA-)

| Flange | Type | Flexible Type | | | | Non-flexible Type | | | |
|-------------|----------|---------------|-------|-------|-------|-------------------|-------|-------|-------|
| | | 3m | 5m | 10m | 20m | 3m | 5m | 10m | 20m |
| 130 | Standard | SC03F | SC05F | SC10F | SC20F | SC03N | SC05N | SC10N | SC20N |
| | Brake | BC03F | BC05F | BC10F | BC20F | BC03N | BC05N | BC10N | BC20N |
| 180 (5.5kW) | Standard | SD03F | SD05F | SD10F | SD20F | SD03N | SD05N | SD10N | SD20N |
| | (~7kW) | SE03F | SE05F | SE10F | SE20F | SE03N | SE05N | SE10N | SE20N |
| 180 | Brake | BD03F | BD05F | BD10F | BD20F | BD03N | BD05N | BD10N | BD20N |
| | | BE03F | BE05F | BE10F | BE20F | BE03N | BE05N | BE10N | BE20N |
| | | BF03F | BF05F | BF10F | BF20F | BF03N | BF05N | BF10N | BF20N |
| 220 | Standard | SH03F | SH05F | SH10F | SH20F | SH03N | SH05N | SH10N | SH20N |
| | Brake | BH03F | BH05F | BH10F | BH20F | BH03N | BH05N | BH10N | BH20N |

Note) Application or :1.2~3.5kW , or :4.4~5.5Kw, or :7Kw~


10.2 AC servo drive

10.2.1 Digital loader (Order code No.: FDA500004S)



10.2.2 CN1 connector (Order code No.: FDACON50P-3M)

Item No.: 10150-3000VE, 10350-52A0-008, Maker: 3M



10.2.3 Noise filter

| AC Servo drive | FDA- 6005C | FDA- 6010C | FDA- 6012C | FDA- 6015C | FDA- 6020C | FDA- 6030C | FDA- 6045C | FDA- 6075CN | FDA- 6110CN | FDA- 6150CN |
|-------------------|---------------|---------------|---------------|---------------|---------------|---------------|----------------|----------------|----------------|----------------|
| NOISE FILTER | | | | NFS-4030SG | | | NFZ- 4040SG | NFZ- 4050SG | NFZ- 4060SG | NFZ- 4080SG |

(Recommended Maker : Samil Components co. www.samilemc.com)


10.2.4 Power unit for brake

Item No.: BPU-109A


| Series Name | | N 60 Series | N 80 Series | CN10/KN07 | N/F 130 Series | N/F 180 Series |
|-------------------------|------------|-------------|-------------|-----------|----------------|----------------|
| Static fraction torque | (kgfcm) | 15 | 26 | 33 | 90 | 360 |
| Dynamic fraction torque | (kgfcm) | 9.0 | 15.6 | 19.8 | 54 | 216 |
| Rated (at 20 °C) | Power(W) | 6.5 | 9 | 9 | 18 | 31 |
| | Voltage(V) | DC 24 | | | DC 90 | |
| | Current(A) | 0.27 | 0.38 | 0.38 | 0.19 | 0.35 |

(Recommended Maker : OGURA co. www.ogura-clutch.com)

10.2.4.1 DC 24V, OPT-12 (Japan, OGURA) or equivalent



10.2.4.2 DC90V, OPR-109 (Japan, OGURA) or equivalent



10.2.5 P-DORI Station (RS232C PC Communication Software)

(Download the program from our website: www.higenmotor.com)

Main Features

Current status display function(motor speed, load rate, etc.)

Alarm status display function


I/O status display function

Convenient mode change and parameter change

Auto jog test function

Setup data backup and file report

Display Window



10.2.6 Multi unit communication model (FDA60 N Model)

Main Features


Two channels communication (RS485, RS232C)

Using general MODBUS protocol

(Download the MODBUS manual from our website: www.higenmotor.com)

Capable of HMI network with the upper control systems(PLC, Motion controller, etc)

10.2.6.1 RS232C & RS485 Network.



18.2.6.2 MODBUS RTU protocol

| Start (Logical) | Address field | Function filed | Data field | CRC check |
|-----------------|---------------|----------------|------------|-----------|
| 3.5 char, Times | 1 Byte | 1 Byte | N × 2 Byte | 2 Byte |

| Field | Contents |
|----------------|----------------------------------|
| Address field | Slave ID (1~31) |
| Function field | Function codes |
| Data field | Data related with function codes |
| CRC check | CRC-16 : X16+X15+X2+1 |

[Appendix] Revision History(FDA6000C)

Homepage : <http://www.higenmotor.com>

Head office :

TEL (82) 2-369-8213~4 FAX (82) 2-369-8229

Branch office :

TEL (82) 51-710-5032~3 FAX (82) 51-710-5034

Factory :

TEL (82) 55-600-3333 FAX (82) 55-600-3317

Customer support :

TEL (82) 2-369-8215
(82) 55-281-8407

Order NO : 7200SV3009A



This book is in copyright. Subject to statutory exception and to the provisions of relevant collective licensing agreements, no reproduction of any part may take place without the written permission of HIGEN Motor company.